

A						UNDERGRUPP BRÄNSLESYSTEM		UNTERGRUPPE KRAFTSTOFFANLAGE		Grupp Gruppe	
B										23	
C										Sida Seite	
D										259	
E											
Pos	Artikel nr Artikelnr.	Antal / Anzahl					P S	Benämning	Bezeichnung	Anmärkning Anmerkung	S R
		A	B	C	D	E					
		-	-	-	-	-		B200E, B230E, B200ET, B230ET, B230F, B230FT, B28E,B28F,B280E,B280F	B200E, B230E, B200ET, B230ET, B230F, B230FT, B28E,B28F,B280E,B280F	SEE 23 • 315	
								Bränslepump med monterings- detaljer	Kraftstoffpumpe mit Einbautei- len		
		-	-	-	-	-		B200E, B230E, B28E, B28F	B200E, B230E, B28E, B28F	SEE 23 • 317	
		-	-	-	-	-		B200ET, B230ET, B230F, ... B230FT,B280E,B280F	B200ET, B230ET, B230F, ... B230FT,B280E,B280F	SEE 23 • 319	
		-	-	-	-	-		Bränsletank och anslutningsdetaljer	Kraftstofftank und Anschlussteile	SEE 23 • 321	
		-	-	-	-	-		Uljämningssystem för bränsletank	Ausgleichsystem für Kraftstofftank	SEE 23 • 325	
		-	-	-	-	-		Extra bränsletank med monteringsdetaljer	Extra Kraftstofftank mit Einbauteilen	SEE 23 • 327	
								Luftfilter	Luftfilter		
		-	-	-	-	-		B230A, B200K, B230K	B230A, B200K, B230K	SEE 23 • 359	
		-	-	-	-	-		B200E, B230E, B230F	B200E, B230E, B230F	SEE 23 • 363	
		-	-	-	-	-		B200ET, B230ET, B230FT ..	B200ET, B230ET, B230FT ..	SEE 23 • 365	
		-	-	-	-	-		B28A, B28E, B28F	B28A, B28E, B28F	SEE 23 • 369	
		-	-	-	-	-		B280E, B280F	B280E, B280F	SEE 23 • 371	
		-	-	-	-	-		D24	D24	SEE 23 • 373	
		-	-	-	-	-		D24T, D24TIC	D24T, D24TIC	SEE 23 • 375	
		-	-	-	-	-		Reparationssats	Reparatursätze	SEE 23 • 377	

