

A							INLOPPSRÖR		EINLASSROHR		Grupp Gruppe
B											25
C											Sida Seite
D											
E							B230F				443
Pos	Artikel nr Artikelnr.	Antal / Anzahl					P S	Benämning	Bezeichnung	Anmärkning Anmerkung	S R
		A	B	C	D	E					
1		1	-	-	-	-	NS	Inloppsrör komplett	Einlassrohr komplett		
2	(1357782)	1	-	-	-	-	SP	• Inloppsrör	• Einlassrohr	REPL 1 PCS 1389200-5, 1 PCS 961575-8, 1 PCS 1367622-6.	4
3	953044-5	3	-	-	-	-		• Pinnskruv	• Stiftschraube		2
4	1326627-5	1	-	-	-	-		• Nippel	• Nippel		2
5	947043-6	1	-	-	-	-		• Nippel	• Nippel		3
6	948990	1	-	-	-	-	OP	• Plugg	• Stopfen		3
7	1276445-2	1	-	-	-	-		• Nippel	• Nippel		3
8	191026-4	1	-	-	-	-		• Propp	• Stöpsel		2
9	1276445-2	1	-	-	-	-		• Nippel	• Nippel		3
10	191026-4	1	-	-	-	-		• Propp	• Stöpsel		2
11	1266539-4	1	-	-	-	-		• Nippel	• Nippel		2
12	943835	1	-	-	-	-	OP	• Plugg	• Stopfen		2
13	1378879-9	1	-	-	-	-	IK	Packning	Dichtung	(1266796)	1
14	945408-3	8	-	-	-	-		Flänsmutter	Bundmutter		2
15	1357760-6	1	-	-	-	-		Stag	Strebe	(1332579)	4
16	949846-0	1	-	-	-	-		Skruv	Schraube		3
17		1	-	-	-	-		Skruv	Schraube	SEE 21•159	
18		1	-	-	-	-	NS	Spjällhus komplett	Klappengehäuse komplett		
19	1332460-3	1	-	-	-	-		• Spjällhus	• Klappengehäuse		3
20	942593-5	2	-	-	-	-		• Bussning	• Buchse		2
21	419568-1	1	-	-	-	-	IK	• Gummiring	• Gummiring		2
22	1326015-3	1	-	-	-	-		• Spjällaxel	• Klappenwelle		2
23	3501595-7	1	-	-	-	-		• Spjällskiva	• Drosselklappe	(419758)	3
24	943781-5	2	-	-	-	-		• Skruv	• Schraube		2
25	1266710-1	1	-	-	-	-		• Fjäder	• Feder		3
26	1266711-9	1	-	-	-	-		• Fjäderhållare	• Federlager		3
27	3547087-1	1	-	-	-	-		• Hävarm	• Hebel	(1336873)	4
28	963106-0	1	-	-	-	-		• Låsmutter	• Sicherungsmutter		2
29	944925-7	1	-	-	-	-		• Stoppskruv	• Anslagschraube		2
30	955780-2	1	-	-	-	-		• Mutter	• Mutter		2
31	948040-1	1	-	-	-	-		• Nippel	• Nippel		2
32	946600-4	1	-	-	-	-		• Nippel	• Nippel		2
33	1326016-1	1	-	-	-	-		• Konsol	• Konsole		3
34	956162-2	2	-	-	-	-		• Skruv	• Schraube		2
35	1336085-4	1	-	-	-	-		• Ventilhus komplett	• Ventilgehäuse komplett		3
36		1	-	-	-	-	NS	• Ventilhus	• Ventilgehäuse		
37	1219554-1	1	-	-	-	-		• Tomgångsskruv	• Leerlaufregulierschraube		3
38	947114-5	1	-	-	-	-	IK	• O-ring	• O-ring		2
39	463766-6	1	-	-	-	-	IK	• Packning	• Dichtung		2
40	959190-0	2	-	-	-	-		• Skruv	• Schraube		2
41	941905-2	2	-	-	-	-		• Fjäderbricka	• Federscheibe		2
41a	949046	1	-	-	-	-	OP	Plugg	Stopfen		3
42	1271488-7	1	-	-	-	-	IK	Packning	Dichtung	(463527)	2
43	941907-8	3	-	-	-	-		Fjäderbricka	Federscheibe		2
44	955782-8	3	-	-	-	-		Mutter	Mutter		2



