







1



© **VOLVO**
Genuine Parts
PV 435 61331

A		1208595, 1208664					AUTOMATIC GEARBOX		AUTOMATVÄXELLÅDA		Group Grupp
B		1208594									43
C		1208397, 1208663									Page
D		1208610, 1208517									Sida
E		1208596, 1208665					ZF22				921
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	(1208596)	-	-	-	-	1	SP	Automatic gearbox	Automatväxellåda		3
	1208665-8	-	-	-	-	1		Automatic gearbox	Automatväxellåda		5
	1208594-0	-	1	-	-	-		Automatic gearbox	Automatväxellåda		5
	(1208397)	-	-	1	-	-	SP	Automatic gearbox	Automatväxellåda		5
	1208663-3	-	-	1	-	-		Automatic gearbox	Automatväxellåda		5
	(1208610)	-	-	-	1	-	SP	Automatic gearbox	Automatväxellåda		5
	(1208595)	1	-	-	-	-	SP	Automatic gearbox	Automatväxellåda		5
	1208664-1	1	-	-	-	-		Automatic gearbox	Automatväxellåda		5
2	1339504-1	1	-	1	-	1		• Torque converter	• Momentomvandlare		4
	1339818-5	-	1	-	-	-		• Torque converter	• Momentomvandlare		4
	1385022-7	-	-	-	1	-		• Torque converter	• Momentomvandlare	(1339654)	4
3	1339501-7	1	1	1	-	1		• Converter housing	• Momentomvandlarkåpa		5
	1339500-9	-	-	-	1	-		• Converter housing	• Momentomvandlarkåpa		5
4	1339507-4	1	1	1	1	1		• Protecting grating	• Skyddsgaller		3
5	973246-2	12	12	12	12	12		• Screw	• Skruv	(955326), ALTER 1 (949366)	2
	965188-6	18	18	18	18	18		• Flange screw	• Flänsskruv	ALTER 2	2
6	970948-6	6	6	6	6	6		• Screw	• Skruv	(955318) ALTER 1	2
	946472-8	6	6	6	6	6		• Flange screw	• Flänsskruv	ALTER 2	2
7	941908-6	18	18	18	18	18		• Spring washer	• Fjäderbricka	ALTER 1	2
8		1	1	1	1	1	NS	• Gearbox housing	• Växellådshus		
		-	-	-	-	-		• • Pump housing - clutch housing	• • Pumphus- kopplingshus	SEE 43 • 925	
		-	-	-	-	-		• • Clutch housing-, planet gear-, output shaft	• • Kopplingshus-, planetväxel-, utgående axel	SEE 43 • 929	
		-	-	-	-	-		• • Overdrive, freewheel-clutch-brake	• • Överväxel, frihjul- koppling-broms	SEE 43 • 935	
8a	1339717-9	1	1	1	1	1		• Rubber ring	• Gummiring		3
9	1339516-5	1	1	1	1	1		• Gasket	• Packning		3
10	1339502-5	1	1	1	1	1		• Housing, rear	• Hus, bakre		4
11	950543-9	2	2	2	2	2		• Locating pin	• Styrpinne		2
12	1339696-5	1	1	1	1	1		• Bolt	• Bolt		4
13	1339698-1	1	1	1	1	1		• Spring	• Fjäder		3
14	1339697-3	1	1	1	1	1		• Pawl	• Spärrhake		4
15	1339703-9	1	1	1	1	1		• Locating plate	• Styrplatta		4
16	1339704-7	1	1	1	1	1		• Locating plate	• Styrplåt		4
17	1339705-4	1	1	1	1	1		• Screw	• Skruv		3
18	1339699-9	1	1	1	1	1		• Push rod	• Tryckstång		3
19		1	1	1	1	1	NS	• Plug	• Plugg		
20	1339706-2	1	1	1	1	1		• Shaft	• Axel		4
21	1339716-1	1	1	1	1	1		• Spring pin	• Rörpinne		2
22	1339707-0	1	1	1	1	1		• Sealing ring	• Tättningsring		3
23	1339708-8	1	1	1	1	1		• Gear selector cam	• Växelväljarkam		3
24	1385047-4	1	1	-	1	1		• Cam	• Kam	(1339712)	4
25	1339715-3	1	1	1	1	1		• Spring	• Fjäder		4
26	1339671-8	1	1	1	1	1		• Gasket	• Packning		3
27	1339676-7	1	1	1	1	1		• Sealing ring	• Tättningsring		3
28	1339677-5	1	1	1	1	1		• Screw	• Skruv		2
29	1339672-6	1	1	1	1	1		• Air nipple	• Luftnippel		3
30	1339674-2	1	1	1	1	1		• O-ring	• O-ring		3
31	1339675-9	1	1	1	1	1		• Lock washer	• Låsbricka		3
32	1339673-4	1	1	1	1	1		• Cover	• Lock		4
33	1385034-2	1	-	-	-	-		• Control system	• Kontrollsystem	SEE 43 • 957	4
	1385021-9	-	1	-	-	-		• Control system	• Kontrollsystem	SEE 43 • 945	4
	1339979-5	-	-	1	-	-		• Control system	• Kontrollsystem	SEE 43 • 951	4
	1385009-4	-	-	-	1	-		• Control system	• Kontrollsystem	SEE 43 • 951	4
	1385035-9	-	-	-	-	1		• Control system	• Kontrollsystem	SEE 43 • 957	4
34	1339721-1	3	3	3	3	3		• Screw	• Skruv		2
35	1339725-2	1	1	1	1	1		• Oil strainer	• Oljesil		3
36	1339724-5	1	1	1	1	1		• O-ring	• O-ring		2
37	1339750-0	5	5	5	5	5		• Screw	• Skruv		2
38	1339723-7	8	8	8	8	8		• Screw	• Skruv		2

A	1208595, 1208664	AUTOMATIC GEARBOX					AUTOMATVÄXELLÅDA					Group Grupp	
B	1208594											43	
C	1208397, 1208663											Page Sida	
D	1208610, 1208517											923	
E	1208596, 1208665												
							ZF22						
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R		
		A	B	C	D	E							
39	1339667-6	8	8	8	8	8	• Sealing ring	• Tätningsring	(1339793)	3			
40	1339665-0	4	4	4	4	4	• Spring	• Fjäder		3			
41	1339666-8	5	5	5	5	5	• Spring	• Fjäder		3			
41a	1339997-7	1	1	1	1	1	• Sealing sleeve	• Tätningsshylsa		3			
42	1339668-4	9	9	9	9	9	• Retaining ring	• Spårring		3			
43	1385020-1	1	1	1	1	1	• Gasket	• Packning		3			
44	1339726-0	1	1	1	1	1	• Sump	• Oljesump		4			
45	1385040-9	4	4	4	4	4	• Brace	• Bygel		2			
46	1385041-7	2	2	2	2	2	• Brace	• Bygel		2			
47	1385042-5	6	6	6	6	6	• Screw	• Skruv		2			
48	1339733-6	1	1	1	1	1	• Gasket	• Packning	(1339732)	2			
49	965768-5	1	1	1	1	1	• Plug	• Plugg		2			
50		1	1	1	1	1	NS • Cap nut	• Överfallsmutter					
51	1339719-5	1	1	1	-	1	• Control cable	• Reglagewire		3			
	1339992-8	-	-	-	1	-	• Control cable	• Reglagewire		3			
52	1339745-0	1	1	1	1	1	• O-ring	• O-ring		3			
53	271696-7	1	1	1	1	1	Repair kit	Reparationssats		3			
							Oil strainer	Oljesil					
54	1339725-2	1	1	1	1	1	• Oil strainer	• Oljesil		3			
55	1339724-5	1	1	1	1	1	• O-ring	• O-ring		2			
56	1385020-1	1	1	1	1	1	• Gasket	• Packning	SEE 43-979	3			
57		1	1	1	1	1	Repair kit	Reparationssats					