




A						INJECTION PUMP		INSPRUTNINGSPUMP		Group Grupp	
B										23	
C										Page Sida	
D										301	
E						D24 TIC					
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	9135965-3	1	-	-	-	-	EU	Injection pump	Insprutningspump	(1389515)	5
	5003641-7	1	-	-	-	-		Injection pump, exch	Insprutningspump, bytes		5
2	1257156-8	1	-	-	-	-	EU	Bracket	Konsol	(970949)	5
3	946752-3	3	-	-	-	-		Flange screw	Flänsskruv		2
4	941908-6	3	-	-	-	-		Spring washer	Fjäderbricka		2
5	960148-5	3	-	-	-	-		Washer	Bricka		2
6	1257259-0	1	-	-	-	-		Support	Stöd		5
7	955296-9	2	-	-	-	-		Screw	Skruv		2
8	941907-8	2	-	-	-	-		Spring washer	Fjäderbricka		2
9	1257634-4	2	-	-	-	-		Washer	Bricka		3
10	1257593-2	1	-	-	-	-		Sleeve	Hylsa		3
11	1257632-8	2	-	-	-	-		Screw	Skruv		2
12	1257633-6	1	-	-	-	-		Screw	Skruv		2
13	941907-8	1	-	-	-	-		Spring washer	Fjäderbricka		2
14	955894-1	1	-	-	-	-		Washer	Bricka		2
15	941907-8	2	-	-	-	-		Spring washer	Fjäderbricka		2
16	955894-1	2	-	-	-	-		Washer	Bricka		2
17	(1257631)	1	-	-	-	-	SP	Screw	Skruv	REPL 1 PCS 947818-1, 1 PCS 960141-0	2
18	941907-8	1	-	-	-	-	EU	Spring washer	Fjäderbricka	(955784)	2
19	1257630-2	1	-	-	-	-		Washer	Bricka		3
20	1257592-4	1	-	-	-	-		Nut	Mutter		3
21	1257166-7	1	-	-	-	-		Pulley	Kuggremhjul		3
22	910113-0	1	-	-	-	-		Key	Kil		2
23	955923-8	1	-	-	-	-		Spring washer	Fjäderbricka		2
24	971072-4	1	-	-	-	-		Nut	Mutter		2
25	1257663-3	1	-	-	-	-		Intermediate section	Mellanstycke		4
26	947282-0	2	-	-	-	-		Gasket	Packning		2
27	3501798-7	1	-	-	-	-		Fuel pipe	Bränslerör		2
28	844237-8	1	-	-	-	-		Hollow screw	Hålskruv		4
29	947282-0	1	-	-	-	-		Gasket	Packning		2
30	947282-0	1	-	-	-	-		Gasket	Packning		2
31	947282-0	1	-	-	-	-		Gasket	Packning		2
32	1257388-7	1	-	-	-	-		Fuel pipe	Bränslerör		3
33	1321718-7	2	-	-	-	-		Clamp	Klamma		2
34	1328101-9	1	-	-	-	-		Nipple	Nippel		3
35	1266870-3	X	-	-	-	-		Hose return	Slang retur		2
36	1257543-7	1	-	-	-	-		Hose clamp	Slangklamma		2