




VOLVO PARTS
1 023 37827
(102:2)

A						INJECTION PUMP		INSPRUTNINGSPUMP		Group Grupp	
B										23	
C										Page Sida	
D										289	
E											
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	1328480-7	1	-	-	-	-		Injection pump	Insprutningspump		5
2	1257678	1	-	-	-	-	OP	• Adjusting screw	• Ställskruv	LG 24 mm	3
	1257677	1	-	-	-	-	OP	• Adjusting screw	• Ställskruv	LG 26 mm	3
	1257679	1	-	-	-	-	OP	• Adjusting screw	• Ställskruv	LG 28 mm	3
3	844235-2	1	-	-	-	-		• O-ring	• O-ring		4
4	25703-0	1	-	-	-	-		• Washer	• Bricka		3
5	955800-8	1	-	-	-	-		• Lock nut	• Låsmutter		2
6	844652	1	-	-	-	-	OP	• Spacer sleeve	• Distanshylsa		3
7	955781-0	2	-	-	-	-		• Nut	• Mutter		2
8	844237-8	1	-	-	-	-		• Hollow screw	• Hålskruv		4
9	844178-4	1	-	-	-	-		• Sealing ring	• Tätningsring		4
10	844176-8	1	-	-	-	-		• O-ring	• O-ring		3
11		2	-	-	-	-	NS	• Screw	• Skruv	M6 LG 18 mm	
12	844176-8	1	-	-	-	-		• O-ring	• O-ring		3
13		2	-	-	-	-	NS	• Screw	• Skruv	M6 LG 18 mm	
14	1257676-5	1	-	-	-	-		• Solenoid valve	• Magnetventil		3
15	942888-9	1	-	-	-	-		• Tab	• Flatstift		2
16	941905-2	1	-	-	-	-		• Spring washer	• Fjäderbricka		2
17	946577-4	1	-	-	-	-		• Lock nut	• Låsmutter		2
18	243572-5	1	-	-	-	-		• O-ring	• O-ring		3
19	244688-8	6	-	-	-	-		• Delivery valve retainer	• Tryckventilhållare		5
20	243560-0	6	-	-	-	-		• Washer	• Bricka		4
21	238309-9	6	-	-	-	-		• Compression spring	• Tryckfjäder		4
22	1257675-7	6	-	-	-	-		• Delivery valve	• Tryckventil		4
23	845738-4	6	-	-	-	-		• Sealing washer	• Tätningsbricka		4
24	1277235-6	1	-	-	-	-		• Set screw idling	• Stoppskruv tomgång		3
25	844228-7	1	-	-	-	-		• Set screw max.revs.	• Stoppskruv max.varv		2
26	1542407-0	1	-	-	-	-		• Sleeve	• Hylsa		3
27	1257741	1	-	-	-	-	OP	• Adjusting washer ignition advance	• Justerbricka tändförställning .		2
28	845737-6	1	-	-	-	-		• Bleeder screw	• Urluftningsskruv		3
29	947620-1	1	-	-	-	-		• Gasket	• Packning		2