

A						BELT TRANSMISSION MANUAL BELT TENSIONER		REMTRANSMISSION MANUELL KAMAXELREMSPÄNNARE		Group Grupp	
B										21	
C										Page Sida	
D										197	
E											
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	3507137-2	1	-	-	-	-		Sealing flange	Tätningsfläns		4
2	965212-4	1	-	-	-	-		Flange screw	Flänsskruv	LG 35 mm.	2
	946544-4	11	-	-	-	-		Flange screw	Flänsskruv	LG 16 mm.	2
3	942001-9	1	-	-	-	-		Screw	Skruv	(963683)	2
4	1276425-4	1	-	-	-	-		Sealing ring	Tätningsring	(1276424)	2
5	1378650-4	1	-	-	-	-		Belt protector	Remskydd		4
6	948893-3	2	-	-	-	-		Flange screw	Flänsskruv		2
7	911234-3	1	-	-	-	-		Spacer tube	Distansrör		4
8	1357563-4	1	-	-	-	-		Belt protector	Remskydd		4
9	948893-3	1	-	-	-	-		Flange screw	Flänsskruv		2
10	1326243-1	1	-	-	-	-		Bal. shaft housing, l.h.	Balansaxelhus, v		5
	1326325-6	1	-	-	-	-		Bal. shaft housing, r.h.	Balansaxelhus, h		5
10a	3547956-7	2	-	-	-	-		Balance shaft	Balansaxel	B204 (1378182)	3
	3547957-5	2	-	-	-	-		Balance shaft	Balansaxel	B234 (1378181)	3
11	3514943-4	2	-	-	-	-		Sealing ring	Tätningsring		2
12	270873-3	1	-	-	-	-		Gasket kit	Packningsats		3
13	1326572-3	2	-	-	-	-		• O-ring	• O-ring		2
14	1326571-5	2	-	-	-	-		• O-ring	• O-ring		2
15	1326573-1	2	-	-	-	-		• O-ring	• O-ring		2
16	1326246-4	2	-	-	-	-		• Sealing washer	• Tätningsbricka		2
17	947542-7	24	-	-	-	-		• Flange screw	• Flänsskruv		2
17a	1161059-9	1	-	-	-	-		Chemical gasket	Flytande packning		6
18	1357939-6	2	-	-	-	-		Screw	Skruv	LG 113 mm.	2
	1326437-9	6	-	-	-	-		Screw	Skruv	LG 98 mm.	2
19	951950-5	1	-	-	-	-		Spring pin	Rörpinne		2
20	270869-1	1	-	-	-	-		Balance shaft bearing kit	Balansaxellagersats		3
21	3531184-4	1	-	-	-	-		Locating plate	Styrplåt		3
22	3514375-9	1	-	-	-	-		Pulley	Kuggremhjul		3
23	1357621-0	1	-	-	-	-		Locating plate	Styrplåt		3
24	3531919-3	2	-	-	-	-		Pulley	Kuggremhjul	(1378126)	3
25	960143-6	2	-	-	-	-		Washer	Bricka		2
26	946752-3	2	-	-	-	-		Flange screw	Flänsskruv	(970949)	2
27	948606-9	1	-	-	-	-		Stud	Pinnskruv		2
28	1357936-2	1	-	-	-	-		Idler pulley	Brytrulle		3
29	945407-5	1	-	-	-	-		Flange nut	Flänsmutter		2
30	1357663-2	1	-	-	-	-		Spacer	Distans		3
31	(1378122)	1	-	-	-	-	SP	Tension pulley	Spännrulle	REPL 1PCS 3547543-3, 1PCS 965221-5. FOR 1378122-4. FOR 3548543-3.	3
32	959242-9	1	-	-	-	-		Screw	Skruv		2
	965221-5	1	-	-	-	-		Flange screw	Flänsskruv		2
33	3547459-2	1	-	-	-	-		Tooth belt	Kuggrem		2
34	1346560-4	1	-	-	-	-		Belt stop	Remstopp		3
35	1378376-6	1	-	-	-	-		Pulley	Kuggremhjul		3
36	9135112-2	1	-	-	-	-		Pulley	Kuggremhjul		3
37	946472-8	1	-	-	-	-		Flange screw	Flänsskruv	(968895)	2
38	1378375-8	2	-	-	-	-		Pulley	Kuggremhjul		3
39	463580-1	2	-	-	-	-		Washer	Bricka		2
40	970952-8	2	-	-	-	-		Screw	Skruv	(955322)	2
41	1326284-5	2	-	-	-	-		Idler pulley	Brytrulle		3
42	965216-5	2	-	-	-	-		Flange screw	Flänsskruv	(955301)	2
43	952996-7	1	-	-	-	-		Stud	Pinnskruv		2
44	1357684-8	1	-	-	-	-		Spacer	Distans		3
45	1346372-4	1	-	-	-	-		Spring	Fjäder		3
46	463386-3	1	-	-	-	-		Spring guide	Fjäderstyrning		3
47	1346373-2	1	-	-	-	-		Stud	Pinnskruv		3
48	1336953-3	1	-	-	-	-		Tension pulley	Spännrulle		3
49	463580-1	1	-	-	-	-		Washer	Bricka		2
50	971071-6	1	-	-	-	-		Nut	Mutter	(955783)	2
51	271720-5	1	-	-	-	-		Tooth belt	Kuggrem		2

A						BELT TRANSMISSION MANUAL BELT TENSIONER		REMTRANSMISSION MANUELL KAMAXELREMSPÄNNARE		Group Grupp		
B										21		
C										Page Sida		
D										B204, B234		
E												199
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R	
		A	B	C	D	E						
52	1378652-0	1	-	-	-	-		Belt protector	Remskydd	(1378726)	4	
53	1320164-5	1	-	-	-	-		• Plug	• Plugg		2	
54	948356-1	1	-	-	-	-		Flange screw	Flänsskruv		2	
55	1378654-6	1	-	-	-	-		Belt protector	Remskydd		4	
56	965213-2	1	-	-	-	-		Flange screw	Flänsskruv		2	
57	968755-9	2	-	-	-	-		Screw	Skruv		2	
58	271929-2	1	-	-	-	-		Belt protector	Remskydd		4	
59	968755-9	1	-	-	-	-		Screw	Skruv		2	
60	968756-7	2	-	-	-	-		Screw	Skruv		2	
61	948356-1	2	-	-	-	-		Flange screw	Flänsskruv		2	