





A					B					C					D					E					REAR DOOR LOCKING SYSTEM					BAKDÖRR LÄSSYSTEM					Group Grupp				
																														83									
																														Page Sida									
																														731									
																														4DRS									
Fig					Part No. Artikel nr					Quantity / Antal					P S					Description					Benämning					Notes Anmärkning					S R				
										A B C D E																													
1					1380929-8					1 - - - -										Lock, l.h.					Lås, v					1)					3				
					1380906-6					1 - - - -										Lock, l.h.					Lås, v					2) EXC (AUS)					3				
					1380929-8					1 - - - -										Lock, l.h.					Lås, v					2) (AUS)					3				
					1380930-6					1 - - - -										Lock, r.h.					Lås, h					1)					3				
					1380907-4					1 - - - -										Lock, r.h.					Lås, h					2) EXC (AUS)					3				
					1380930-6					1 - - - -										Lock, r.h.					Lås, h					2) (AUS)					3				
2					1320863-2					1 - - - -										• Clip					• Clips										2				
3					1320864-0					1 - - - -										• Bushing					• Bussning										2				
4					956057-4					2 - - - -										Screw					Skruv										2				
5					3503941-1					1 - - - -										Motor					Motor					2)					3				
6					968381-4					1 - - - -										• Tab housing					• Stiftisolator					2)					3				
7					968373-1					2 - - - -										• Cable terminal					• Ledningssko					2)					3				
9					949947-6					2 - - - -										Screw					Skruv					2)					2				
10					1320322-9					1 - - - -										Lock, l.h.					Lås, v										3				
					1320323-7					1 - - - -										Lock, r.h.					Lås, h										3				
11					1355226-0					4 - - - -										Screw					Skruv										2				
12					1380074-3					2 - - - -										Lock brace					Låsbygel										3				
13					1316087-4					X - - - -										Shim					Justerbleck										3				
14					3503873-6					4 - - - -										Screw					Skruv										2				
15					1320314-6					1 - - - -										Door opener, l.h.					Dörröppnare, v										3				
					1320315-3					1 - - - -										Door opener, r.h.					Dörröppnare, h										3				
16					1320316-1					2 - - - -										Return spring					Returfjäder										2				
17					958246-1					2 - - - -										Screw					Skruv										2				
18					1203311-4					2 - - - -										Washer					Bricka										3				
19					1255989-4					2 - - - -										Spring nut					Fjädermutter										2				
20					1203658-8					2 - - - -										Clip					Clips										2				
21					1316145-0					2 - - - -										Handle, black					Handtag, svart										3				
					1316146-8					2 - - - -										Handle, blue					Handtag, blå										3				
					3503173-1					2 - - - -										Handle, beige					Handtag, beige										3				
					3503174-9					2 - - - -										Handle, red					Handtag, röd										3				
					3503175-6					2 - - - -										Handle, grey					Handtag, grå										3				
22					955119-3					2 - - - -										Screw					Skruv										2				
23					1316150-0					2 - - - -										Plug, black					Propp, svart										3				
					1316151-8					2 - - - -										Plug, blue					Propp, blå										3				
					3503176-4					2 - - - -										Plug, beige					Propp, beige										3				
					3503177-2					2 - - - -										Plug, red					Propp, röd										3				
					3503178-0					2 - - - -										Plug, grey					Propp, grå										3				
24																				Guide					Styrning					SEE 85-793									
25					1316934-7					2 - - - -										Link					Länk					1)					3				
					1334872-7					2 - - - -										Link					Länk					2) EXC (AUS)					3				
					1316934-7					2 - - - -										Link					Länk					2) (AUS)					3				
26					1203219-9					2 - - - -										Lock button, black					Låsknapp, svart					1)					2				
					1334830-5					2 - - - -										Lock button, black					Låsknapp, svart					2) EXC (AUS)					2				
					1203219-9					2 - - - -										Lock button, black					Låsknapp, svart					2) (AUS)					2				
					1316928-9					2 - - - -										Lock button, blue					Låsknapp, blå					1)					2				
					1334831-3					2 - - - -										Lock button, blue					Låsknapp, blå					2) EXC (AUS)					2				
					1316928-9					2 - - - -										Lock button, blue					Låsknapp, blå					2) (AUS)					2				
					1380821-7					2 - - - -										Lock button, beige					Låsknapp, beige					1)					2				
					1380824-1					2 - - - -										Lock button, beige					Låsknapp, beige					2) EXC (AUS)					2				
					1380821-7					2 - - - -										Lock button, beige					Låsknapp, beige					2) (AUS)					2				
					1380822-5					2 - - - -										Lock button, red					Låsknapp, röd					1)					2				
					1380825-8					2 - - - -										Lock button, red					Låsknapp, röd					2) EXC (AUS)					2				
					1380822-5					2 - - - -										Lock button, red					Låsknapp, röd					2) (AUS)					2				
					1380823-3					2 - - - -										Lock button, grey					Låsknapp, grå					1)					2				
					1380826-6					2 - - - -										Lock button, grey					Låsknapp, grå					2) EXC (AUS)					2				
					1380823-3					2 - - - -										Lock button, grey					Låsknapp, grå					2) (AUS)					2				
27					1380009-9					1 - - - -										Lever, l.h.					Hävarm, v										3				
					1380010-7					1 - - - -										Lever, r.h.					Hävarm, h										3				
28					1304766-7					2 - - - -										Clamp					Klamma										3				

- 1) Cars without central locking system. / Bilar utan centrallåsning.
2) Cars with central locking system. / Bilar med centrallåsning.

A							REAR DOOR LOCKING SYSTEM		BAKDÖRR LÅSSYSTEM		Group Grupp
B											83
C											Page Sida
D											733
E							4DRS				
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
29	969476-1	2	-	-	-	-		Screw	Skruv	3)	2
30	1268198-7	1	-	-	-	-		Link, l.h.	Länk, v		3
	1268199-5	1	-	-	-	-		Link, r.h.	Länk, h		3
31	1304766-7	4	-	-	-	-		Clamp	Klamma		3
32	1316220-1	4	-	-	-	-		Guide	Styrning		3
33	1380517-1	1	-	-	-	-		Handle, l.h. bright	Handtag, v blank		2
	1380519-7	1	-	-	-	-		Handle, l.h. black	Handtag, v svart		2
	1380518-9	1	-	-	-	-		Handle, r.h. bright	Handtag, h blank		2
	1380520-5	1	-	-	-	-		Handle, r.h. black	Handtag, h svart		2
34	1268806-5	1	-	-	-	-		• Trim moulding bright	• Prydnadslist blank		3
	1268805-7	1	-	-	-	-		• Trim moulding black	• Prydnadslist svart		3
35	955781-0	1	-	-	-	-		• Nut	• Mutter		2
36	951951-3	1	-	-	-	-		• Spring pin	• Rörpinne		2
37	3503041-0	2	-	-	-	-		Gasket	Packning		2
38	3503042-8	2	-	-	-	-		Gasket	Packning		2
39	955269-6	2	-	-	-	-		Screw	Skruv		2
40	955892-5	2	-	-	-	-		Washer	Bricka		2
41	956060-8	2	-	-	-	-		Screw	Skruv		2
42	955891-7	2	-	-	-	-		Washer	Bricka		2
43	965175-3	2	-	-	-	-		Flange screw	Flänsskruv		2
44	3526223-7	2	-	-	-	-		Link	Länk	3	

3) Spare part version / Reservdelsutförande.