




VOLVO
 Genuine Parts
 PV 640 48007

A							STEERING STEERING GEAR STEERING		STYRNING STYRVÄXEL RATTAXEL		Group Grupp
B							SHAFT				64
C											Page Sida
D											801
E											
Fig	Part No. Artikel nr	Quantity / Antal					P S	Description	Benämning	Notes Anmärkning	S R
		A	B	C	D	E					
1	(1359340)	1	-	-	-	-	SP	Steering gear	Styrväxel	1) CAM L.H.D REPL 1 PCS 1387500-0.	2
	5003604-5	1	-	-	-	-	EU	Steering gear, exch	Styrväxel, bytes		4
	(1359341)	1	-	-	-	-	SP	Steering gear	Styrväxel	1) CAM R.H.D REPL 1 PCS 1387501-8.	4
	5003605-2	1	-	-	-	-	EU	Steering gear, exch	Styrväxel, bytes		4
	1387500-0	1	-	-	-	-		Steering gear	Styrväxel	1) CAM L.H.D	5
	5003682-1	1	-	-	-	-	EU	Steering gear, exch	Styrväxel, bytes		5
	1387501-8	1	-	-	-	-		Steering gear	Styrväxel	1) CAM R.H.D	5
	5003683-9	1	-	-	-	-	EU	Steering gear, exch	Styrväxel, bytes		5
		-	-	-	-	-		•SEE 64•811	•SEE 64•811		
	(1359495)	1	-	-	-	-	SP	Steering gear	Styrväxel	2) ZF L.H.D REPL 1 PCS 1359340-5.	5
	(3516940)	1	-	-	-	-	SP	Steering gear	Styrväxel	3) ZF L.H.D REPL 1 PCS 1387500-0.	5
		-	-	-	-	-		•SEE 64•813	•SEE 64•813		
2	968682-5	2	-	-	-	-		Flange screw	Flänsskruv		2
3	971098-9	2	-	-	-	-		Flange lock nut	Flänslåsmutter	(949279)	2
4	946109-6	2	-	-	-	-		Lock nut	Låsmutter	ALTER 1	2
	971099-7	2	-	-	-	-		Flange lock nut	Flänslåsmutter	ALTER 2	2
5	3516086-0	1	-	-	-	-		Universal joint	Universalknut		4
6	977107-2	3	-	-	-	-		Flange screw	Flänsskruv	(1272992)	3
7	948645-7	3	-	-	-	-		Flange lock nut	Flänslåsmutter	(946036)	2
8	664822-4	3	-	-	-	-		Lock spring	Låsfjäder		1
9	3516087-8	1	-	-	-	-		Steering shaft	Rattaxel		4
10	1387457-3	1	-	-	-	-		Seal	Tätning		3
11	942679-2	2	-	-	-	-		Blind rivet	Blindnit	EXC (t),(RI),(MAL).	2
	941806-2	2	-	-	-	-		Blind rivet	Blindnit	(t),(RI),(MAL)	2
12	1387458-1	1	-	-	-	-		Rail	Skena		3
13	(3516050)	1	-	-	-	-	SP	Steering shaft	Rattaxel	REPL 1 PCS 6819220-2, 1 PCS 6819378-8, 1 PCS 951978-6.	4
13a	968798-9	2	-	-	-	-		•Spring nut	•Fjädermutter		2
14	973285-0	4	-	-	-	-		Sems screw	Semsskruv	(1387733)	2
15	1387060-5	1	-	-	-	-		Slip ring	Släpring		3
16	1359731-5	1	-	-	-	-		Contact unit	Kontaktenhet	AIR BAG	3
17	969407-6	3	-	-	-	-		Screw	Skruv	(956078)	2
18	1359648-1	1	-	-	-	-		Lever	Spak		4
19		-	-	-	-	-		Column lock	Rattlås	SEE 36•453	
19a		1	-	-	-	-		Starter switch	Startkontakt	SEE 36•453	
20	976137-0	1	-	-	-	-		Flange screw	Flänsskruv	(3516114)	2
21	951078-5	1	-	-	-	-		Retaining ring	Spärring		2
22		-	-	-	-	-		Steering wheel	Ratt	SEE 64•821	
23	1359032-8	1	-	-	-	-		Cover, upper	Kåpa, övre		4
24	1359034-4	1	-	-	-	-		Cover, lower	Kåpa, undre		4
25	972322-2	4	-	-	-	-		Screw	Skruv	(949947)	2
26	969500-8	2	-	-	-	-		Six point socket screw	Sextandhålskruv	(946933)	2
27	951666-7	1	-	-	-	-		E-circlip	Spärryttare		2

1) Service plate marked 2. / Serviceskylten märkt 2.

2) Service plate marked 3. / Serviceskylten märkt 3.

3) 740 4DRS CH 294100-. 740 5DRS CH 176800-.