


Pos Fig.	Antal Qty.	Benämning	Description	Det. nr Part No.	Anmärkning Notes
1	1	Tryckpump	Master cylinder	653094-3	
2	1	. Hus	. Housing	S E S	
3	1	. Påfyllningslock	. Filler cap	656479-3	
4	1	. Packning	. Gasket	656480-1	
5	1	. Kolv	. Plunger	656481-9	1)
6	1	. Kolv	. Plunger	669948-2	2)
7	1	. Gummipackning, inre	. Rubber packing, inner	656458-7	1)
	1	. Gummipackning, inre	. Rubber packing, inner	669949-0	2)
8	1	. Gummipackning, yttre	. Rubber packing, outer	656483-5	1, 3)
9	1	. Returfjäder	. Return spring	656354-8	1, 4)
	1	. Returfjäder	. Return spring	669950-8	2, 5)
10	1	. Hållare	. Retainer	656355-5	
11	1	. Ventilspindel	. Valve stem	656356-3	
12	1	. Gummipackning	. Rubber packing	656357-1	
13	1	. Ventilstyrning	. Valve guide	656358-9	
14	1	. Bricka, fjädrande	. Washer, sprung	656359-7	
15	1	. Tryckstång	. Push rod	653092-7	
16	1	. Bricka	. Washer	656484-3	
17	1	. Låsring	. Lock ring	656485-0	
18	1	. Gummikåpa	. Rubber casing	656486-8	



1. Tid utf.
 2. Sen utf.
 3. Ers av: 1 st 669949-0, 1 st 669950-8.
 4. 10 varv.
 10 coils.
 10 revolutions.
 10 windungen.
 10 espiras.

5. 13 varv.
 13 coils.
 13 revolutions.
 13 windungen.
 13 espiras.