

LUCAS

EQUIPMENT & SPARE PARTS

Spares List No.

1973

N.V.S. 1916
March 1963

VOLVO
P1800

SPARE PARTS

Further to N.V.S.1916 this vehicle is now being produced in Sweden, equipment is as shown below:-

BULBHOLDER, CLOCK ILLUMINATION AND PANEL LIGHT		Headlamp 58651B cont'd...	
Part No.	54944812	§ Nut, rim fixing screw	187117
Bulb	†987	Bracket, fixing rim	555704
BULBHOLDER, MAP LIGHT		§ Plate, retaining light unit	54520549
Part No.	554734	Screw, fixing unit retaining plate	186137
Bulb	†987	Rim, unit seating	54520446
FLASHER UNIT		§ Gasket, body	54520711
Part No.	35020A	§ Adaptor	553738
Model	FL5	Spring, fixing unit seating rim	54520514
FUSE BOXES		Screw, trimmer	54520451
Part No.	54038033	Housing, trimmer screw nut	54520550
Model	4FJ	Nut, trimmer screw	54520551
§ Fuse, 35 amp.	188218	LAMP, NUMBER PLATE ILLUMINATION AND REVERSE	
§ Cover	54380114	Part No.	53999A
§ Screw, terminal	120560	Model	706
Part No.	54038035	§ Cover	54573363
Model	5FJ	Screw, fixing cover	186194
§ Fuse, 35 amp.	188218	§ Glass, number plate illumination	54573680
Cover	54380108	§ Glass, reverse	54573364
LAMP, HEAD (Less Light Unit)		§ Gasket, seating glass	54573366
Part No.	†58651B	§ Bulbholder, number plate illumination	554710
Model	F700 Mk X	Interior, bulbholder	553780
§ Rim or door	54521155	Ring, seating bulbholder	554354
§ Screw, fixing rim	198898	Bulb, number plate illumination	989
Washer, retaining screw	161385	Bulbholder, reverse	556284
		Interior, bulbholder, reverse	573832
		Bulb, reverse	382

Continued...

JOSEPH LUCAS LTD · BIRMINGHAM 18 · ENGLAND

Number Plate Illumination and Reverse Lamp 53999A cont'd...

Gasket, seating lamp	54573367
Grommet, cable entry	574049
Grommet, cable entry	54572247
Body	54573368

LAMP, SIDE AND FLASHER

Part No.	752592A/D
Model	714
Rim or door with lens	754573428
Lens	754574026
Gasket, seating lens	576805
Sliding ring	574616
Interior, bulbholder, flasher	573832
Bulb, flasher	382
Interior, bulbholder, side	553780
Bulb, side	989
Gasket, seating lamp	754573429
Body	754573372
Nut, fixing lamp	54131266
Washer, fixing nut	188330

LAMP, STOP TAIL AND FLASHER (Left Hand, Amber & Red)

Part No.	754122B
Model	671
Lens	754573966
Screw, fixing lens	54110101
Washer, retaining screw	164722
Gasket, seating lens	54571195
Interior, bulbholder, flasher	573832
Bulb, flasher	382
Interior, bulbholder, stop tail	573828
Bulb, stop tail	380
Grommet, cable entry, stop tail	54572202
Gasket, seating base	54571804
Gasket, seating lamp	54571811
Base	54571688
Nut, fixing lamp	54131266
Washer, fixing nut	188483
Grommet, cable entry, flasher	54572247

(Right Hand, Amber & Red)

Part No.	754123B
Model	671

Base 54571689

Other details as 54122B.

(Left Hand, Red)

Part No.	53899D
Model	671

Lens 54572039

Stop Tail and Flasher Lamp 53899D cont'd.

Grommet, cable entry 576401
Other details as 54122B.

(Right Hand, Red)

Part No. 53901D
Model 671

Lens 54572039

Base 54571689

Grommet, cable entry 576401

Other details as 54122B.

RELAY, HEADLAMP

Part No. 33188D
Model 6RA

RELAY, HORN

Part No. 33231B
Model 6RA

STEERING COLUMN CONTROL

Part No. 733566A
Model CC5

Cover 54300479

Plate, contact, upper 54300013

Plate, contact, lower and fixing

cup 54300605

Screw, fixing 186136

Knob, Horn Push 54300482

SWITCH, COURTESY

Part No. 31828D
Model 65SA

Nut, fixing 153601

Washer, fixing nut 54148517

SWITCH, DIPPER

Part No. 31800B
Model 21SA

Pad, insulating 360373

SWITCH, HEATER FAN

Part No. *34519A
(34317)
Model 58SA

Nut, fixing 153636

Washer, fixing nut 186106

Knob #54332781

Escutcheon plate(English) #54332783

Escutcheon plate(Swedish) #54334687

Continued...

SWITCH, HORN

Part No.	34322A
Model	23SA
Nut, fixing, front	153631
Washer, fixing nut	54148517
Nut, fixing, rear	153636

SWITCH, LIGHTING

Part No.	34323B
Model	10SA
Knob	‡54332781
Bezel	‡313630
Escutcheon plate (English)	‡54332782
Escutcheon plate (Swedish)	‡54334685

SWITCH, ROOF LAMP

Part No.	31743D/E
Model	57SA
Nut, fixing	153631
Washer, fixing nut	54148517

SWITCH, STOP LAMP

Part No.	31882B
Model	HL2

SWITCH, WINDSHIELD WIPER

Part No.	34324B
Model	10SA
Knob	‡54332781
Bezel	‡313630
Escutcheon plate (English)	‡54332784
Escutcheon plate (Swedish)	‡54334686

WARNING LIGHTS

Bulbholder, Flasher, Ignition and
Main Beam

Part No.	319408
Bulb	‡987

OVERDRIVE

Cover and Window	54360477
Shade	319222
Bulbholder	554734
Bulb	987

SCREENWIPER SPINDLE BUSH

Part No.	54713111
----------	----------

SCREENWIPER SPINDLE GASKET

Part No.	54713113
----------	----------

OVERDRIVE EQUIPMENT

RELAY

Part No.	332
Model	

SWITCH, GEARBOX

Part No.	318
Model	S

SWITCH, OPERATING

Part No.	318
Model	6

Nut, fixing	153
Washer, fixing nut	54148
Escutcheon plate (English)	‡54334
Escutcheon plate (Swedish)	‡54334

SOLENOID

Part No.	76522
Model	

Cover, contact	765
Cover, rubber	765
Boot, rubber, plunger	765
Plunger	54640

CABLE SUNDRIES

Eyelet $\frac{1}{4}$ "	850
Eyelet $\frac{3}{8}$ "	850
Eyelet $\frac{3}{16}$ "	850
Eyelet $\frac{5}{16}$ "	900
§Lucar, connector (17.5 amp)	54942
Sleeve	54190
§Lucar, connector (17.5 amp - double)	54942
Sleeve	54190
Nipple, connector	900
Tube, connector (2 way)	900
Tube, connector (4 way)	850
Grommet, diaphragm	863
Grommet, handbrake	54948
Holder, panel light	54947
Holder, panel light	54360

¶ New item.

|| Serviced by vehicle manufacturer.

* When ordering, quote part number shown in brackets.

‡ Order separately.

† Complete control serviced by vehicle manufacturer.

§ Recommended spares for stock.