

Wiring diagram Volvo 121/122 S

www.ClassicKabelboomCompany.com

A = White B = Black C = Blue D = Green E = Grey F = Yellow G = Brown
H = Red I = Spare lead

- | | | |
|--|---|--|
| 1. Flasher and parking light, left | 23. Fusebox | wiper and washer |
| 2. Headlight, left | 24. Brake contact | 43. Lighting switch |
| 3. Horn | 25. Door contact, left | 44. Ignition switch |
| 4. Headlight, right | 26. Light signal device | 45. Cigarette lighter |
| 5. Flasher and parking light, right | 27. Horn | 46. Switch for ventilation fan |
| 6. Connector | 28. Overdrive switch ¹⁾ | 47. Glove compartment lighting |
| 7. Junction block | 29. Roof light | 48. Switch for glove compartment lighting |
| 8. Relay for headlight signal | 30. Switch for roof light | 49. Fuel gauge pickup |
| 9. Reverse light contact | 31. Flasher unit, direction indicators | 50. Rear lamp, left, with rear light, stop light, flasher and back-up light |
| 10. Distributor | 32. Door contact, right | 51. Number plate light |
| 11. Dynamo | 33. Control lamp for charging | 52. Rear lamp, right, with rear light, stop light, flasher and reverse light |
| 12. Charging regulator | 34. Control lamp for main beam headlights | |
| 13. Relay for reverse light | 35. Control lamp for direction indicators | |
| 14. Relay for overdrive ¹⁾ | 36. Control lamp for oil pressure | |
| 15. Overdrive contact ¹⁾ | 37. Fuel gauge | |
| 16. Ignition coil | 38. Windscreen wiper | |
| 17. Oil pressure warning indicator | 39. Instrument lighting | |
| 18. Foot dipper switch | 40. Ventilation fan | |
| 19. Solenoid for overdrive ¹⁾ | 41. Control lamp for overdrive | |
| 20. Starter motor | 42. Control for windscreen | |
| 21. Windscreen washer | | |

¹⁾ Applies only to cars equipped with overdrive

