



- 1 Flasher and parking light, left
- 2 Headlight, left
- 3 Spot light, right-hand drive (fog light for left-hand drive)
- 4 Horn
- 5 Fog light, right-hand drive (spot light for left-hand drive)
- 6 Headlight, right
- 7 Flasher and parking light, rear
- 8 Connector
- 9 Relay for fog light
- 10 Junction block
- 11 Relay for spot light
- 12 Relay for headlight signal
- 13 Switch on gearbox for reverse light
- 14 Distributor
- 15 Relay for horn
- 16 Relay for reverse light
- 17 Fusebox
- 18 Relay for overdrive
- 19 Switch for overdrive on gearbox
- 20 Ignition coil
- 21 Oil pressure pickup
- 22 Alternator
- 23 Charging regulator
- 24 Foot dipper switch
- 25 Solenoid for overdrive
- 26 Engine compartment light
- 27 Starter motor
- 28 Windscreen washer
- 29 Battery
- 30 Speedometer
- 31 Brake switch
- 32 Door switch, left
- 33 Light signal device, direction indicators
- 34 Horn
- 35 Overdrive switch
- 36 Roof light
- 37 Roof light switch
- 38 Flasher unit, direction indicators
- 39 Door switch, right
- 40 Warning lamp for charging
- 41 Control lamp for main beam headlights
- 42 Control lamp for direction indicators
- 43 Warning lamp for oil pressure
- 44 Fuel gauge
- 45 Instrument lighting
- 46 Windscreen wiper
- 47 Heater
- 48 Control lamp for overdrive
- 49 Switch for fog light
- 50 Switch for spot light
- 51 Switch for windscreen wiper and washer
- 52 Switch for spot light and parking light
- 53 Ignition switch
- 54 Cigarette lighter
- 55 Heater switch
- 56 Glove compartment light
- 57 Switch for glove compartment
- 58 Fuel gauge pickup
- 59 Rear lamp, left
- 60 Luggage compartment light
- 61 Number plate light
- 62 Rear lamp, right

**Wire colour code**

- A = White
- B = Black
- C = Blue
- D = Green
- E = Grey
- F = Yellow
- G = Brown
- H = Red
- I = Spare lead