



VOLVO PARTS  
 2 040 38400  
 (15-2)

A			KOPPLING KOPPLINGSMANÖVRERING		CLUTCH OPERATING SYSTEM		Grupp Group				
							41				
							Sida Page				
							193				
B											
C											
D											
E											
Pos	Artikel nr Part No.	Antal /Quantity					P S	Benämning	Description	Anmärkning Notes	S R
		A	B	C	D	E					
1	430123-0	1	-	-	-	-		Koppling .....	Clutch .....		2
2	1526213-2	1	-	-	-	-		Lamell .....	Driven plate .....	(1561670)	2
3	955294-4	6	-	-	-	-		Skruv .....	Screw .....		2
4	941907-8	6	-	-	-	-		Fjäderbricka .....	Spring washer .....		2
5	1205729-5	1	-	-	-	-		Huvudcylinder .....	Master cylinder .....		3
		-	-	-	-	-		•SEE 41•195 .....	•SEE 41•195 .....		1
6		1	-	-	-	-		Konsol .....	Bracket .....	SEE 52•263	
7	1569256-9	1	-	-	-	-		Kopplingspedal .....	Clutch pedal .....	CH-10799	5
	6894070-9	1	-	-	-	-		Kopplingspedal .....	Clutch pedal .....	CH 10800-	5
		2	-	-	-	-	NS	•Bussning .....	•Bushing .....		
8		1	-	-	-	-		Pedalskoning .....	Pedal pad .....	CH-10799	3
9	1569233-8	1	-	-	-	-		Pedalskoning .....	Pedal pad .....	CH 10800-	3
	631567-5	1	-	-	-	-		Pedalskoning .....	Pedal pad .....		
10	955894-1	2	-	-	-	-		Bricka .....	Washer .....		2
11	952841	1	-	-	-	-	OP	Saxpinnebult .....	Clevis pin .....		2
12	1569232-0	2	-	-	-	-		Returfjäder .....	Return spring .....		2
13		1	-	-	-	-		Axel .....	Shaft .....	SEE 52•263	
14	907824-7	2	-	-	-	-		Saxpinne .....	Split pin .....		2
15	1569230	1	-	-	-	-	OP	Hållare .....	Retainer .....	CH-10799	3
	1567174-6	1	-	-	-	-		Konsol .....	Bracket .....	CH 10800-	4
16	955297-7	2	-	-	-	-		Skruv .....	Screw .....		2
17	941907-8	2	-	-	-	-		Fjäderbricka .....	Spring washer .....		2
18	968862-3	2	-	-	-	-		Flänsmutter .....	Flange nut .....	(955782)	8
19	1569833-5	1	-	-	-	-		Banjonippel .....	Banjo nipple .....		3
20	18839-1	2	-	-	-	-		Packning .....	Gasket .....		2
21	1569832-7	1	-	-	-	-		Hålskruv .....	Hollow screw .....		3
22	(1569834)	1	-	-	-	-	SP	Rör .....	Pipe .....	REPL 946814-1, 2PCS 946816-6 LG 740	3
22a	946814-1	X	-	-	-	-		Bundyrör .....	Bundy pipe .....		2
	946816-6	2	-	-	-	-		Mutter .....	Nut .....		2
23	1569840-0	1	-	-	-	-		Nippel .....	Nipple .....		3
24	(1569838)	1	-	-	-	-	SP	Rör .....	Pipe .....	REPL 946814-1, 2PCS 946816-6 LG 1320	3
24a	946814-1	X	-	-	-	-		Bundyrör .....	Bundy pipe .....		2
	946816-6	2	-	-	-	-		Mutter .....	Nut .....		2
25	941908-6	2	-	-	-	-		Fjäderbricka .....	Spring washer .....		2
26	191487-8	2	-	-	-	-		Klamma .....	Clamp .....	(1569837)	2
27	969473-8	2	-	-	-	-		Skruv .....	Screw .....	(955137)	2
28	678986-1	1	-	-	-	-		Urkopplingsgaffel .....	Release fork .....		3
29	678985-3	1	-	-	-	-		Urkopplingslager .....	Release bearing .....		2
30	940135-7	1	-	-	-	-		Skruv .....	Screw .....		2
31	267329-1	1	-	-	-	-		Hävarm .....	Lever .....		4
32	907824-7	1	-	-	-	-		Saxpinne .....	Split pin .....		2
33	913113-7	1	-	-	-	-		Styrtapp .....	Guide pin .....		2
34	(1569508)	1	-	-	-	-	SP	Manövercylinder .....	Control cylinder .....	REPL 1PCS 1697713-4 1PCS 1569960-6 1PCS 1207377-1 1PCS 1569183-5	3
☆	1697713-4	1	-	-	-	-		Manövercylinder .....	Control cylinder .....		3
		-	-	-	-	-		•SEE 41•195 .....	•SEE 41•195 .....		
35	6868391-1	1	-	-	-	-		Hydraulslang .....	Hydraulic hose .....		2
36		1	-	-	-	-	NS	Konsol .....	Bracket .....		
37	6868392-9	1	-	-	-	-		Clips .....	Clip .....		2
38	943488-7	1	-	-	-	-		Tätning .....	Seal .....		2
39	914463-5	1	-	-	-	-		Spärring .....	Retaining ring .....		2
40	947818-1	1	-	-	-	-		Skruv .....	Screw .....	CH 10800-	2
☆	968862-3	1	-	-	-	-		Flänsmutter .....	Flange nut .....	(955782) CH 10800-	8