



A			DRIVANDE FRAMAXEL		DRIVEN FRONT AXLE		Grupp Group				
							46				
							Sida Page				
							229				
Pos	Artikel nr Part No.	Antal /Quantity					P S	Benämning	Description	Anmärkning Notes	S R
		A	B	C	D	E					
1	1522883-6	1	-	-	-	-		Framaxel .....	Front axle .....		5
		-	-	-	-	-		SEE 46-231 .....	SEE 46-231 .....		
2	634567-2	1	-	-	-	-		Luftventil .....	Air valve .....		3
3	6868196-4	2	-	-	-	-		Framhjulsnav .....	Front wheel hub .....		4
4	6868205-3	10	-	-	-	-		• Bult .....	• Bolt .....		2
5	181311-2	4	-	-	-	-		• Yttering .....	• Cup .....		2
6	181312-0	4	-	-	-	-		Innerring .....	Cone .....		2
7	636869-0	2	-	-	-	-		Bricka .....	Washer .....		3
8	636669-4	2	-	-	-	-		Distanshylsa .....	Spacer sleeve .....		3
9	940366-8	X	-	-	-	-		Justerbleck .....	Shim .....	THK 0.10	2
	940367-6	X	-	-	-	-		Justerbleck .....	Shim .....	THK 0.35	2
10	191035-5	2	-	-	-	-		Tätningring .....	Sealing ring .....		2
11	634586-2	2	-	-	-	-		Packning .....	Gasket .....		2
12	960711-0	8	-	-	-	-		Skruv .....	Screw .....		2
13	941909-4	8	-	-	-	-		Fjäderbricka .....	Spring washer .....		2
14	631283-9	2	-	-	-	-		Navkapsel .....	Hub cap .....		3
15		2	-	-	-	-		Bromstrumma .....	Brake drum .....	SEE 51-257	
16		2	-	-	-	-		Framhjulsbroms .....	Front wheel brake .....	SEE 51-257	
17	1569210-6	1	-	-	-	-		Distansring .....	Spacer ring .....		3
	1569211-4	1	-	-	-	-		Distansring .....	Spacer ring .....		3
18	955675-4	12	-	-	-	-		Skruv .....	Screw .....		2
19	942336-9	12	-	-	-	-		Fjäderbricka .....	Spring washer .....		2
20	192240-0	12	-	-	-	-		Skruv .....	Screw .....		2
21	942336-9	12	-	-	-	-		Fjäderbricka .....	Spring washer .....		2
22		1	-	-	-	-		Medbringare .....	Companion flange .....	SEE 46-231	