




VOLVO PARTS  
2 023 24603  
(5:1)

A							P S		BRÄNSLETANK DETALJER, MONTERINGSDETALJER		FUEL TANK PARTS, FITTINGS		Grupp Group
									L.H.D		23		
											Sida Page		
											83		
B	C	D	E										
Antal /Quantity													
Pos	Artikel nr Part No.	A	B	C	D	E		Benämning	Description	Anmärkning Notes		S R	
1	1560579-3	1	-	-	-	-		Bränsletank .....	Fuel tank .....	R.H.D, SPCL S-3780. SEE 23-85		4	
	643251-2	1	-	-	-	-		Bränsletank .....	Fuel tank .....	83L		4	
1 a	15304-9	1	-	-	-	-		• Packning .....	• Gasket .....	FOR 643251-2		2	
1 b	960630-2	1	-	-	-	-		• Propp .....	• Plug .....	FOR 643251-2		2	
2	955537-6	2	-	-	-	-		Skruv .....	Screw .....			2	
3	960148-5	2	-	-	-	-		Bricka .....	Washer .....			2	
4	62080-7	2	-	-	-	-		Fjäder .....	Spring .....			2	
5	960142-8	2	-	-	-	-		Bricka .....	Washer .....			2	
6	950354-1	4	-	-	-	-		Låsmutter .....	Lock nut .....			2	
7	1560085-1	1	-	-	-	-		Fästjärn .....	Attaching plate .....			3	
8	1560086-9	1	-	-	-	-		Fästplatta .....	Attaching plate .....			3	
9	640900-7	1	-	-	-	-		Tankarmatur .....	Combined tank unit .....			2	
10	950021-6	5	-	-	-	-		Skruv .....	Screw .....			2	
11	120150-8	5	-	-	-	-		Bricka .....	Washer .....			2	
12	944133-8	1	-	-	-	-		Slang .....	Hose .....			2	
13	943480-4	2	-	-	-	-		Slangklamma .....	Hose clamp .....			2	
14	1561164-3	1	-	-	-	-		Rör .....	Pipe .....			4	
	1565742-2	1	-	-	-	-		Rör .....	Pipe .....	1)		4	
14 a	1566593-8	1	-	-	-	-		Påfyllningsrör .....	Filler pipe .....	TGB 20		4	
15	190666-8	2	-	-	-	-		Skruv .....	Screw .....			2	
	955513-7	2	-	-	-	-		Skruv .....	Screw .....	1)		2	
16	960147-7	2	-	-	-	-		Bricka .....	Washer .....			2	
16 a	941906-0	2	-	-	-	-		Fjäderbricka .....	Spring washer .....	1)		2	
16 b	950352-5	2	-	-	-	-		Låsmutter .....	Lock nut .....	1)		2	
17	1560128-9	1	-	-	-	-		Sil .....	Strainer .....			3	
17 a	1566760-3	1	-	-	-	-		Sil .....	Strainer .....	TGB 20		2	
18	1560515-7	1	-	-	-	-		Lock .....	Cover .....			1	
	662463-9	1	-	-	-	-		Lock .....	Cover .....	1)		1	
18 a	1566761-1	1	-	-	-	-		Påfyllningslock .....	Filler cap .....	TGB 20		1	
18 b	313705-6	X	-	-	-	-		Kedja .....	Chain .....	LG 500		4	
18 c	88495-7	2	-	-	-	-		Nyckelring .....	Key ring .....			4	
18 d	1566815	1	-	-	-	-	NS	Låsfjäder .....	Lock spring .....			4	
19	943392-1	1	-	-	-	-		Hålnit .....	Semi-tubular rivet .....			2	
19 a	940100-1	2	-	-	-	-		Skruv .....	Screw .....	TGB 20		2	
19 b	941906-0	2	-	-	-	-		Fjäderbricka .....	Spring washer .....	TGB 20		2	
19 c	955825-5	2	-	-	-	-		Mutter .....	Nut .....	TGB 20		2	
20	947945-2	X	-	-	-	-		Plastslang .....	Plastic hose .....	(637983)		2	
	947945-2	X	-	-	-	-		Plastslang .....	Plastic hose .....	TGB 20		2	
21	943473-9	2	-	-	-	-		Slangklamma .....	Hose clamp .....			2	
22	1336649-7	X	-	-	-	-		Slang .....	Hose .....	(192034)		2	
23	951190-8	1	-	-	-	-		Klamma .....	Clamp .....			2	
24	969278-1	1	-	-	-	-		Skruv .....	Screw .....	(955138)		2	
25	1563205	1	-	-	-	-	NS	Bränsletank extra bränsletank .	Fuel tank extra fuel tank .....	2) 40L		1	
26	662463-9	1	-	-	-	-		Lock .....	Cover .....	2)		1	
27		2	-	-	-	-	NS	Stöd .....	Support .....	2)		2	
28	1563219	2	-	-	-	-	NS	Spännband .....	Tensioning band .....	2)		2	
29	1609966-5	X	-	-	-	-		Gummilist .....	Rubber moulding .....	2) (1508026)		2	
30	961970-1	4	-	-	-	-		Gummibussning .....	Rubber bushing .....	2)		2	
31	960144-4	4	-	-	-	-		Bricka .....	Washer .....	2)		2	
32	950354-1	4	-	-	-	-		Låsmutter .....	Lock nut .....	2)		2	

1) SPCL S-3736, S-3802.

2) SPCL S-3652, S-3653.



**VOLVO**  
Genuine Parts  
LV230 53040

A						P S	Benämning	Description	Anmärkning Notes	S R						
	B										BRÄNSLETANK DETALJER, MONTERINGSDETALJER	FUEL TANK PARTS, FITTINGS	Grupp Group			
		C											23			
			D										Sida Page			
				E									85			
						R.H.D, SPCL S-3780.										
Pos	Artikel nr Part No.	Antal /Quantity														
		A	B	C	D	E										
1	1560312-9	1	-	-	-	-	Bränsletank .....	Fuel tank .....	HB 2300, 125L	4						
	1560579-3	1	-	-	-	-	Bränsletank .....	Fuel tank .....	HB 2530, 150L	4						
2	1562210-3	2	-	-	-	-	Konsol .....	Bracket .....	(1561563)	4						
3	940115-9	8	-	-	-	-	Skruv .....	Screw .....		2						
4	960142-8	16	-	-	-	-	Bricka .....	Washer .....		2						
	955950-1	1	-	-	-	-	Låsbricka .....	Lock washer .....		2						
5	950354-1	8	-	-	-	-	Låsmutter .....	Lock nut .....		2						
6	1560581-9	2	-	-	-	-	Upphångningsband .....	Mounting strap .....		3						
7	1505541-1	X	-	-	-	-	Gummlist .....	Rubber moulding .....		2						
8	190509-0	2	-	-	-	-	Bricka .....	Washer .....		2						
9	950354-1	2	-	-	-	-	Låsmutter .....	Lock nut .....		2						
10	955551-7	2	-	-	-	-	Skruv .....	Screw .....		2						
11	955896-6	4	-	-	-	-	Bricka .....	Washer .....		2						
12	1561559-4	2	-	-	-	-	Distanshylsa .....	Spacer sleeve .....		4						
13	1561560-2	1	-	-	-	-	Tvärstag .....	Cross stay .....	HB 2300	3						
	1561561-0	1	-	-	-	-	Tvärstag .....	Cross stay .....	HB 2530	5						
14	1560128-9	1	-	-	-	-	Sil .....	Strainer .....		3						
15	1560515-7	1	-	-	-	-	Lock .....	Cover .....		1						
16	943392-1	1	-	-	-	-	Hålnit .....	Semi-tubular rivet .....		2						
17	(352087)	1	-	-	-	-	SP Tankarmatur .....	Combined tank unit .....	REPL 1PCS 1588122-0, 1 PCS 273709-6.	3						
	1588122-0	1	-	-	-	-	Bränslenivågivare .....	Fuel gauge sensor .....		3						
☆ 17a	273709-6	1	-	-	-	-	Isolatorsats .....	Insulator kit .....	FOR 1588122-0	4						
☆ 17b	949005-3	1	-	-	-	-	• Isolator .....	• Housing .....		3						
☆ 17c	949371-9	4	-	-	-	-	• Ledningssko .....	• Cable terminal .....		1						
☆ 17d	1580973-4	3	-	-	-	-	• Plugg .....	• Plug .....		4						
18	89865-0	1	-	-	-	-	Packning .....	Gasket .....		2						
19	950021-6	5	-	-	-	-	Skruv .....	Screw .....		2						
20	120150-8	5	-	-	-	-	Bricka .....	Washer .....		2						
☆ 21	1336649-7	X	-	-	-	-	Slang .....	Hose .....	(192034)	2						
22	952625-2	1	-	-	-	-	Klamma .....	Clamp .....		2						
23	950021-6	1	-	-	-	-	Skruv .....	Screw .....		2						
24	955893-3	1	-	-	-	-	Bricka .....	Washer .....		2						
25	941903-7	1	-	-	-	-	Pinne .....	Pin .....		2						
26	940092-0	1	-	-	-	-	Mutter .....	Nut .....		2						
27	954313-3	X	-	-	-	-	Bundyrör .....	Bundy pipe .....		2						
28	18335-0	1	-	-	-	-	Klamma .....	Clamp .....		2						
29	955140-9	1	-	-	-	-	Skruv .....	Screw .....		2						
30	1562207-9	1	-	-	-	-	Skyddsplåt .....	Protecting plate .....		5						
31	955524-4	6	-	-	-	-	Skruv .....	Screw .....		2						
32	960141-0	6	-	-	-	-	Bricka .....	Washer .....		2						
33	950353-3	6	-	-	-	-	Låsmutter .....	Lock nut .....		2						
34	1561311-0	1	-	-	-	-	Tankskydd .....	Tank protection .....		3						
35	969473-8	3	-	-	-	-	Skruv .....	Screw .....	(955137)	2						