

A							VÄRMEANLÄGGNING		HEATER SYSTEM		Grupp	
B							BAKRE		REAR		87	
C											Sida	
D											Page	
E											497	
Pos	Artikel nr Part No.	Antal /Quantity					P S	Benämning	Description	Anmärkning Notes	S R	
		A	B	C	D	E						
1	644147-1	1	-	-	-	-		Bilvärmare	Heater unit	24V	5	
	1562676	1	-	-	-	-	NS	Bilvärmare	Heater unit	1) 24V		
	1563230-0	1	-	-	-	-		Bilvärmare	Heater unit	12V SPCL S-3656, 3736, 3694, 3695, 3696.	5	
2	644148-9	1	-	-	-	-		• Kåpa	• Casing		5	
	1565219-1	1	-	-	-	-		• Kåpa	• Cover	1)	6	
3	1502340-1	1	-	-	-	-		• Värmeväxlare	• Heat exchanger		3	
4		X	-	-	-	-	NS	• Tätningslist	• Sealing strip			
5	644152-1	1	-	-	-	-		• Ram	• Frame		5	
	1562130-3	1	-	-	-	-		• Ram	• Frame	1)	6	
6	955512-9	6	-	-	-	-		• Skruv	• Screw		2	
7	941906-0	6	-	-	-	-		• Fjäderbricka	• Spring washer		2	
8	644156-2	1	-	-	-	-		• Stödben	• Support		5	
	1562131-1	1	-	-	-	-		• Stödben	• Support	1)	6	
9	955512-9	2	-	-	-	-		• Skruv	• Screw		2	
10	941906-0	2	-	-	-	-		• Fjäderbricka	• Spring washer		2	
	940155-5	2	-	-	-	-		• Låsbricka	• Lock washer	1)	2	
11	955825-5	2	-	-	-	-		• Mutter	• Nut		2	
12	(640983)	1	-	-	-	-	SP	• Motor	• Motor	24V REPL 1PCS 6894147-5	3	
	(668606)	1	-	-	-	-	SP	• Motor	• Motor	1PCS 6894173-1. 12V SPCL S-3656, 3694, 3695, 3696. REPL 1PCS 6894151-7, 1PCS 6894173-1.	3	
	6894147-5	1	-	-	-	-		• Motor	• Motor	24V	3	
	6894151-7	1	-	-	-	-		• Motor	• Motor	12V	3	
13	655874-6	1	-	-	-	-		• Gummiring	• Rubber ring		3	
14	653214-7	1	-	-	-	-		• Fläkt	• Fan		3	
15	190674	1	-	-	-	-	OP	• Bricka	• Washer		2	
16	653217	1	-	-	-	-	OP	• Bussning	• Bushing		3	
17	951263-3	1	-	-	-	-		• Skruv	• Screw		2	
18	655875-3	1	-	-	-	-		• Fäste	• Anchorage		5	
	6894173-1	1	-	-	-	-		• Fläktmotorhållare	• Fan motor retainer		5	
19	955512-9	4	-	-	-	-		• Skruv	• Screw		2	
20	941906-0	4	-	-	-	-		• Fjäderbricka	• Spring washer		2	
21	955825-5	1	-	-	-	-		• Mutter	• Nut		2	
22	641083-1	1	-	-	-	-		• Ledningsmatta	• Cable harness		5	
23	91395-4	1	-	-	-	-		• Gummibussning	• Rubber bushing		2	
24	1560668-4	1	-	-	-	-		• Skärmsplåt	• Shield		5	
24a	1562129	1	-	-	-	-	OP	• Luftfördelare	• Air distributor	1)	6	
25	969473-8	2	-	-	-	-		• Skruv	• Screw	(955137)	2	
	955125-0	2	-	-	-	-		• Skruv	• Screw	1)	2	
26	955511-1	3	-	-	-	-		• Skruv	• Screw	CH-4162, CIVIL CH-5346.	2	
	955511-1	2	-	-	-	-		• Skruv	• Screw	CH 4163- CIVIL CH 5347-	2	
	940100-1	1	-	-	-	-		• Skruv	• Screw	CH 4163- CIVIL CH 5347-	2	
27	941906-0	3	-	-	-	-		• Fjäderbricka	• Spring washer		2	
28	1563549-3	1	-	-	-	-		• Filter	• Filter	1)	3	
29	956060-8	2	-	-	-	-		• Skruv	• Screw	1)	2	
30	955945-1	2	-	-	-	-		• Låsbricka	• Lock washer	1)	2	
31	955779-4	2	-	-	-	-		• Mutter	• Nut	1)	2	
32	1565220-9	1	-	-	-	-		• Kondensator	• Capacitor	1)	6	
33	950020-8	2	-	-	-	-		• Skruv	• Screw	1)	2	
34	955946-9	2	-	-	-	-		• Låsbricka	• Lock washer	1)	2	
35	940092-0	2	-	-	-	-		• Mutter	• Nut	1)	2	

1) Radioavstörd. / Disturbance elimination.