





Sida	Grupp	Växellåda	Gearbox	Illustration Utgåva					
36	4	BW35	BW35	5					
Page	Group			10693 Issue					
Pos. Fig.	Antal/Quantity			Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	254 617	254 677	254 708						
1	1	—	—	254617-4	Växellåda .....	Gearbox .....	4	182 CH-37549.	010
	—	1	—	254677-8	Växellåda .....	Gearbox .....	4	182 CH37550-, 183. B20E	020
	—	—	1	254708-1	Växellåda .....	Gearbox .....	8	182 CH37550-, 183. B20F ERS AV 254677-8	030 040
2	1	1	1	235879-4	•Konverter .....	•Converter .....	4	(235954)	050
3	1	1	1	235736-6	•Konverterkåpa .....	•Converter housing .....			070
4	2	2	2	235814-1	•Skyddsnet .....	•Stone guard .....			080
5	6	6	6	940135-7	•Skruv .....	•Screw .....	0		090
6	6	6	6	955921-2	•Fjäderbricka .....	•Spring washer .....	0		100
7	1	1	1		•Hus med planetväxel .....	•Planet cover .....		SE SIDA 40	110
8	1	1	1	235922-2	•Bakre gavel .....	•Extension housing .....	4		120
9	1	1	1	235728-3	••Tätningring .....	••Oil seal .....	S		130
10	1	1	1		•Packning .....	•Gasket .....	S		140
11	4	4	4	235918-0	•Skruv .....	•Bolt .....			150
12	4	4	4	940110-0	•Fjäderbricka .....	•Spring washer .....	0		160
13	1	—	—	235902-4	•Kontrollsystem .....	•Valve bodies .....	4		170
	—	1	1	235983-4	•Kontrollsystem .....	•Valve bodies .....	4		180
	—	—	—		••Det se sida 44 .....	••Components see page 44 .....			190
14	1	1	1	940117-5	•Skruv .....	•Bolt .....	0		200
15	1	1	1	955920-4	•Fjäderbricka .....	•Spring washer .....	0		210
16	2	2	2	955516-0	•Skruv .....	•Bolt .....	0		220
17	2	2	2	955920-4	•Fjäderbricka .....	•Spring washer .....	0		230
18	1	1	1	235705-1	•Inloppsrör, främre pump .....	•Tube front pump inlet .....	3		240
19	1	1	1	235527-9	•O-ring .....	•O-ring .....	S		250
20	1	1	1	235704-4	•Utloppsrör, främre pump .....	•Tube front pump outlet .....	3		260
21	1	1	1	235706-9	•Inloppsrör, konverter .....	•Tube converter inlet .....	3		270
22	1	1	1	235848-9	•Utloppsrör, konverter .....	•Tube converter outlet .....	3		280
23	1	1	1	235701-0	•Rör främre servo .....	•Tube front servo .....	3		290
24	1	1	1	235853-9	•Rör främre servo .....	•Tube front servo .....	3		300
25	1	1	1	235703-6	•Rör bakre koppling .....	•Tube rear clutch .....	3		310
26	1	1	1	235707-7	•Rör bakre servo .....	•Tube rear servo .....	3		320
27	1	—	—	672393-6	•Reglagewire .....	•Cable .....	2		330
	—	1	1	235985-9	•Reglagewire .....	•Cable .....	2		340
27a	1	1	1	1220513-4	•Kabelstopp .....	•Cable stop .....			345
28	1	1	1	235812-5	•Packning .....	•Packing .....	1		350
29	1	1	1		•Kam .....	•Cam .....		SE SIDA 44	360
30	1	1	1	1220558-9	•Startspärr-och back- ljuskontakt, 6-stift .....	•Inhibitor-and back- lamp switch, 6-pin .....		(235965, 1220508) (1220509)	380 390
31	1	1	1	941442-6	••Låsmutter .....	••Lock nut .....	0	TID UTF.	390
31a	1	1	1	235812-5	•Packning .....	•Packing .....		SEN UTF.	395
32	1	—	—	235808-3	•Axel .....	•Manual valve lever shaft .....			400
	—	1	1	235907-3	•Axel .....	•Manual valve lever shaft .....			410
33	1	—	—	235711-9	•Fjäder .....	•Spring .....	3		420
34	1	—	—	235836-4	•Hävvarm .....	•Manual valve lever .....			430
	—	1	1	235979-2	•Hävvarm .....	•Manual valve lever .....			440
35	1	1	1	235845-5	•Låspinne .....	•Slotted spring pin .....			450
36	1	—	—	235712-7	•Ring .....	•Collar .....			460
37	1	—	—	235713-5	•Låspinne .....	•Slotted spring pin .....			470
38	2	1	1		•Tätningring .....	•Seal ring .....		SE SIDA 40	480
39	1	1	1	60309-2	•Kula .....	•Ball .....	3		490
40	1	1	1	235714-3	•Fjäder .....	•Spring .....	3	(235908)	500
41	1	—	—	235827-3	•Dragstång .....	•Linkage rod .....	4		510
	—	1	1	235972-7	•Dragstång .....	•Linkage rod .....	4		520



Sida Page	38	Grupp Group	4	Växellåda BW35	Gearbox BW35	Illustration Utgåva 10693 Issue	3
--------------	----	----------------	---	-------------------	-----------------	------------------------------------	---

Pos. Fig.	Antal/Quantity			Detail nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes		
	254 617	254 677	254 708							
41a	2	2	2	—	235656-6	•Låsfjäder .....	•Retaining spring .....	3		010
42	1	1	1	—	235826-5	•Hävarm .....	•Torsion lever .....	4		020
43	1	1	1	—	235652-5	•Fjäder .....	•Toggle lever spring .....	3		030
44	1	1	1	—		•Lagertapp .....	•Pivot pin .....		SE SIDA 40	040
45	1	1	1	—	41561-2	•Bricka .....	•Washer .....			050
46	1	1	1	—	235654-1	•Låsfjäder .....	•Retaining spring .....	3		060
47	1	1	1	—	235651-7	•Hävarm .....	•Toggle lift lever .....	4		070
48	1	1	1	—	235641-8	•Hänke .....	•Toggle link .....	3		080
49	1	1	1	—	235640-0	•Hävarm .....	•Pawl .....	4		090
50	1	1	1	—	235642-6	•Tapp .....	•Pin .....	3		100
51	1	1	1	—	235643-4	•Hävarm .....	•Toggle lever .....	4		110
52	1	1	1	—	235792-9	•Tapp .....	•Pin .....	3		120
53	1	1	1	—	235793-7	•Fjäder .....	•Release spring .....	3		130
54	1	1	1	—	235648-3	•Lagertapp .....	•Toggle pin .....	4		140
55	1	1	1	—	235649-1	•O-ring .....	•O-ring .....	5		150
56	1	1	1	—	235650-9	•Pinne .....	•Anchor pin .....	4		160
57	1	1	1	—	951956-2	•Låspinne .....	•Slotted spring pin .....	0		170
58	1	1	1	—	235857-0	•Oljesump .....	•Oil pan .....	4		180
59	1	1	1	—	235739-0	•Magnet .....	•Magnet .....			190
60	1	1	1	—		•Packning .....	•Gasket .....	5		200
61	15	15	15	—	955523-6	•Skruv .....	•Screw .....	0		210
63	1	1	1	—	235859-6	•Avtappningspropp .....	•Drain plug .....	1		230
64	1	1	1	—	235858-8	•Packning .....	•Packing .....	1		240
65	—	1	1	—	235927-1	•Låspinne .....	•Lock pin .....			250
66	—	1	1	—	235783-8	•Hattplugg .....	•Plug .....			260
67	—	1	1	—	235928-9	•Låsring .....	•Snap ring .....			270
	1	1	1	—	276501-4	Gummi- och tätning- ringsats .....	Rubber and seal ring kit .....	2		280
	1	1	1	—	273221-2	Packningssats .....	Gasket kit .....	1		290
										300

004  
005010  
020  
030  
040  
050  
060  
070  
080  
090  
100  
110  
120  
130  
140  
150  
160  
170  
180  
190  
200  
210  
230  
240  
250  
260  
270  
280  
290  
300