



VOLVO PARTS  
1 060 10582



Sida	Grupp	Framaxel, styrning	Front axle, steering,	Illustration Utgåva						
4	6	nav, hjul	hubs, wheels	2						
Page	Group			10582 Issue						
Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	VST	HST								
48a	4	4	—	—	682086-4	Hjulring .....	Wheel ring .....	1	182 CH 30001-. 183	010
48b	4	4	—	—	1212376-6	Skyddshylsa .....	Guard sleeve .....			011
49	2	2	—	—	665045-1	Medbringare .....	Companion flange .....	4	182 CH-30000 EXCL USA, CA	020
	1	—	—	—	665045-1	Medbringare .....	Companion flange .....	4	USA, CAN.	030
	1	1	—	—	665045-1	Medbringare .....	Companion flange .....	4	182 CH 30001-. 183	040
50	1	—	—	—	682080-7	Hylsa .....	Sleeve .....	4	USA, CAN	050
	1	1	—	—	682080-7	Hylsa .....	Sleeve .....	4	182 CH 30001-. 183	060
51	1	—	—	—	681979-1	Mutter .....	Nut .....		USA, CAN	070
	1	1	—	—	681979-1	Mutter .....	Nut .....		182 CH 30001-. 183	080
52	ERF	ERF	—	—	940162-1	Skruv .....	Bolt .....	0		090
53	ERF	ERF	—	—	950354-1	Mutter .....	Nut .....	0		10
54	1	1	—	—	664428-0	Kopplingskiva .....	Connecting disc .....	3		110
55	4	4	—	—	192027-1	Skruv .....	Bolt .....	0		120
56	4	4	—	—	950353-3	Mutter .....	Nut .....	0		130
57	1	1	—	—	664430-6	Rattstång .....	Steering shaft .....	3	182 CH-30000	140
58	1	1	—	—	665290-3	Rattrör .....	Column tube .....		182 CH-30000	150
59	2	2	—	—	668144-9	Kullager .....	Ball bearing .....	2	182 CH-30000	16
60	2	2	—	—	85612-0	•Fjäder .....	•Spring .....	3		170
61	2	2	—	—	85613-8	•Säte .....	•Seat .....	3		180
62	1	1	—	—	914456-9	Låsring .....	Circlip .....	0	182 CH-30000 (664437)	190
63	1	1	—	—	191622-0	Bricka .....	Washer .....	0	182 CH-30000	200
64	1	1	—	—	682650-7	Rattstång .....	Steering shaft .....	3	182 CH 30001-35782	210
	1	1	—	—	685356-8	Rattstång .....	Steering shaft .....		182 CH 35783-38653	220
									183 CH-796	221
									ERS AV 121 2290-9,	222
									121 2291-7, 687109-9	223
	1	1	—	—	1212290-9	Rattstång .....	Steering shaft .....	3	182 CH 38654-	224
									183 CH 797-	225
65	1	1	—	—		•Rattrör .....	•Column tube .....	8		230
66	2	2	—	—	85611-2	•Kullager .....	•Ball bearing .....	2		240
67	2	2	—	—	85612-0	•Fjäder .....	•Spring .....	3		250
68	2	2	—	—	85613-8	•Säte .....	•Seat .....	3		260
69	1	1	—	—	914456-9	•Låsring .....	•Circlip .....	0		270
70	1	1	—	—	942270-0	•Mutter .....	•Nut .....	0		280
71	1	1	—	—	665112-9	Stöd, övre .....	Support, upper .....		182 CH-30000	290
72	3	3	—	—	665834-8	Justermellanlägg .....	Shim .....		182 CH-30000	300
73	1	1	—	—	683447-7	Stöd, övre .....	Support, upper .....		182 CH 30001-. 183	310
74	1	1	—	—	680404-1	Mellanlägg .....	Spacer .....		182 CH 30001-. 183	32
75	1	1	—	—	665115-2	Konsol .....	Bracket .....		182 CH 30001-. 183	330
76	1	1	—	—	683230-7	Klammer .....	Clamp .....		182 CH 30001-. 183	340
77	1	—	—	—	665113-7	Stöd, undre .....	Support, lower .....			350
	—	1	—	—	665123-6	Stöd, undre .....	Support, lower .....			360
78	1	1	—	—	665297-8	Klammer .....	Clamp .....			370
79	2	2	—	—	659365-1	Gummibussning .....	Rubber bushing .....		182 CH-30000	38
	2	2	—	—	676317-1	Gummibussning .....	Rubber bushing .....		182 CH 30001-. 183	390
80	ERF	ERF	—	—	955513-7	Skruv .....	Bolt .....	0	1/4-20 UNC	400
	ERF	ERF	—	—	955638-2	Skruv .....	Bolt .....	0	1/4-28 UNF	410
	ERF	ERF	—	—	955523-6	Skruv .....	Bolt .....	0	5/16-18 UNC	420
	ERF	ERF	—	—	955655-6	Skruv .....	Bolt .....	0	5/16-24 UNF	430
81	ERF	ERF	—	—	682898-2	Skruv .....	Bolt .....		5/16-18 UNC	440
82	ERF	ERF	—	—	950372-3	Mutter .....	Nut .....	0	1/4-20 UNF	450
	ERF	ERF	—	—	950352-5	Mutter .....	Nut .....	0	1/4-20 UNC	460
83	ERF	ERF	—	—	955893-3	Bricka .....	Washer .....	0		470
84	ERF	ERF	—	—	955920-4	Fjäderbricka .....	Spring washer .....	0	DI 6,5	480
	ERF	ERF	—	—	955921-2	Fjäderbricka .....	Spring washer .....	0	DI 8,5	490
85	1	1	—	—	654011-6	Tätningsskrage .....	Seal collar .....	4		500
86	1	1	—	—	668648-9	Klammer .....	Clamp .....			510
87	1	1	—	—	955137-5	Skruv .....	Screw .....	0		520
88	1	1	—	—	940090-4	Bricka .....	Washer .....	0		530
89	1	1	—	—		Medbringare .....	Companion flange .....		SE GRUPP 3	540
90	1	1	—	—		Hus .....	Housing .....		SE GRUPP 3	550
91	3	3	—	—	955117-7	Skruv .....	Screw .....	0		560

004

010

011

020

030

040

050

060

070

080

090

10

110

120

130

140

150

16

170

180

190

200

210

220

221

222

223

224

225

230

240

250

260

270

280

290

300

310

32

330

340

350

360

370

38

390

400

410

420

430

440

450

460

470

480

490

500

510

520

530

540

550

560



Sida		Grupp		Framaxel, styrmng		Front axle, steering		Illustration Utgåva		
6		6		nav, hjul		hubs, wheels		1		
Page		Group						10582 Issue		
Pos. Fig.	Antal/Quantity				Detalj nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	VST	HST								
92	1	1	—	—	673423-0	Ratt .....	Steering wheel .....	2		010
93	1	1	—	—	673514-6	•Kontaktring .....	•Contact ring .....			020
94	1	1	—	—	951124-7	•Räffelpinne .....	•Grooved straight pin .....	0		030
95	1	1	—	—	673516-1	•Signalring .....	•Horn ring .....	3		040
96	1	1	—	—	673518-7	••Kontaktbricka .....	••Contact washer .....			050
97	3	3	—	—	673521-1	••Isolerbussning .....	••Insulating bushing .....	3		060
98	1	1	—	—	673522-9	••Isolerbricka .....	••Insulating washer .....	3		070
99	3	3	—	—	673524-5	••Taggbricka .....	••Tag washer .....	2		080
100	3	3	—	—	673523-7	••Tryckfjäder .....	••Thrust spring .....	3		090
101	3	3	—	—	673520-3	••Bricka .....	••Washer .....	3		100
102	3	3	—	—	673519-5	••Ansatsskruv .....	••Stop screw .....	3		110
103	1	1	—	—	673526-0	Stötskydd .....	Shock guard .....	3		120
	—	—	—	—		Signalledning .....	Horn cable .....		SE GRUPP 3	130
	2	2	—	—	273160-2	Framhjulslagersats .....	Front wheel bearing kit .....	1		140