



Grupp Group		10		P 180 (B18)			VOLVO	
Sida Page	20	Utgåva Issue	4	Generator	238621	Generator	Reservdelskatalog Parts catalogue	
Pos Fig.	Antal Qty.	Benämning		Description	Def. nr Part No. Volvo	Def. nr Part No. Bosch		
	1	Generator .....		Generator .....	238621-7	LJ/GG 240/12- 2400 AR 7	0 101 302 027	
1		. Polhus .....		. Yoke .....	S. E. S.	S. E. S.		
2		. Polsko .....		. Pole terminal .....	S. E. S.	S. E. S.		
3	2	. Skruv .....		. Screw .....	190888-8	NSR 5576/22	2 910 551 284	
4	1	. Fältlindning, spole 1 (röd) .....		. Field winding, coil 1 (red) .....	240561-8	LJWC 16 L 15	1 104 103 024	
	1	. Fältlindning, spole 2 (blå) .....		. Field winding, coil 2 (blue) .....	240562-1	LJWC 16 L 16	1 104 103 025	
5	1	. Isolerremsa .....		. Insulating strip .....	S 77674-0	WBA 504/388	3 131 007 000	
6	1	. Anslutningsskruv, klämma DF		. Connecting screw, DF ...	238866-8	WSR 75 L 30	1 103 454 006	
7	1	. Anslutning, klämma D+		. Connector, D+ .....	238790-0	LJEA 19 L 9	1 101 332 009	
8	2	. Isolerplatta .....		. Insulating plate .....	S 238791-8	LJPT 7 L 7	1 101 031 013	
9	2	. Isolerbussning .....		. Insulating bushing .....	S 238792-6	WNB 410/3	1 000 307 010	
10	4	. Isolerbricka .....		. Insulating washer .....	S 238865-0	NNS 27/15	1 900 112 307	
11	4	. Fjäderbricka .....		. Spring washer .....	955920-4	NMS 727/7	2 916 060 006	
12	4	. Mutter .....		. Nut .....	S 955780-2	NMU 42/2	2 915 012 006	
13	1	. Skruv, D- .....		. Screw, D- .....	104306-6	NSR 5450/13	2 911 121 150	
14	1	. Fjäderbricka .....		. Spring washer .....	S 955920-4	NMS 727/7	2 916 060 006	
	2	. Gummituff .....		. Rubber cap .....	S 76614-7	WNK 500/4	3 130 558 000	
15	1	. Drivlager .....		. Driving end bearing .....	238793-4	LJLG 42 L 1	1 105 823 020	
16	1	. Kommutatorlager .....		. Commutator end bearing .....	238794-2	LJLG 41 L 1	1 105 853 181	
17	2	. Borsthållare .....		. Brush holder .....	S 238795-9	LJSA 8 L 1	1 101 323 070	
18	1	. Isolerplatta .....		. Insulating plate .....	S 238796-7	LJPT 19 L 9	1 101 022 002	
19	1	. Anslutningsplatta .....		. Terminal plate .....	S 238797-5	LJPT 18 L 12	1 101 021 005	
20	1	. Underläggsplatta .....		. Base plate .....	S 238799-1	LJPT 18 L 13	1 101 021 006	
21	4	. Nit .....		. Rivet .....	S 238798-3	WNJ 18 L 4	1 103 132 005	
22	2	. Isolerbussning .....		. Insulating bushing .....	S 77511-4	WNB 578/106	1 100 308 006	
23	2	. Isolerbricka .....		. Insulating washer .....	S 48492-3	NNS 101/4	1 900 112 203	
24	1	. Elborstsats .....		. Carbon brush .....	273500-9	1 107 014 141	1 107 014 141	
25	2	. Borstfjäder .....		. Brush spring .....	238801-5	WSF 40 L 4	1 104 652 005	
26	2	. Skruv .....		. Screw .....	S 956058-2	NSR 5596/7	2 910 021 115	
27	2	. Fjäderbricka .....		. Spring washer .....	S 955917-0	NMS 440/3	2 916 690 003	
28	1	. Skruv .....		. Screw .....	S 956058-2	NSR 5596/9	2 910 021 116	
29	1	. Fjäderbricka .....		. Spring washer .....	S 955917-0	NMS 440/3	2 916 690 003	
30	2	. Skruv .....		. Screw .....	190721-1	WSR 30 L 26	1 103 410 008	
31	2	. Fjäderbricka .....		. Spring washer .....	S 955919-6	NMS 440/5	2 916 693 005	
32	1	. Rotor .....		. Rotor .....	238804-9	LJAN 21 L 99	1 104 013 943	
33	1	. Fjädderring .....		. Spring ring .....	238805-6	WMR 61 L 21	1 104 601 005	
34	1	. Oljeskyddsbricka .....		. Splash ring .....	238806-4	LJMS 4 L 7	1 100 120 023	
35	1	. Täckbricka .....		. Cover disk .....	238807-2	LJPT 24 L 1	1 100 551 040	
36	1	. Kullager .....		. Ball bearing .....	11010-6	NKL 20/17	1 900 900 305	
37	1	. Oljeskyddsbricka .....		. Splash ring .....	233774-9	LJMS 7 L 11	1 100 500 058	
38	1	. Mellanring .....		. Intermediate ring .....	77691-4	WMR 618 L 70	2 010 202 000	
39	1	. Mellanring .....		. Intermediate ring .....	233776-4	WMR 22 L 4	1 100 202 000	
40	1	. Oljeskyddsbricka .....		. Splash ring .....	233775-6	LJMS 7 L 5	1 100 500 056	
41	1	. Kullager .....		. Ball bearing .....	11009-8	NKL 20/15	1 900 900 303	
42	2	. Skruv .....		. Screw .....	S 956060-8	NSR 5252/17	2 910 011 120	

Grupp Group		10		P 180 (B18)			VOLVO	
Sida Page	22	Utgåva Issue	5	Generator	238621	Generator	Reservdelskatalog Parts catalogue	
Pos Fig.	Antal Qty.	Benämning	Description	Def. nr Part No. Volvo	Def. nr Part No. Bosch			
43	2	. Fjäderbricka .....	. Spring washer .....	S 955917-0	NMS 440/3	2 916 690 003		
44	1	. Fjädderring .....	. Washer .....	S 233667-5	WMR 51 L 1	1 100 150 000		
45	1	. Kil .....	. Woodruff key .....	S 910115-5	NKE 5/2	1 900 023 008		
46	1	. Remskiva .....	. Belt pulley .....	238623-3	LJRJ 8 L 10	1 106 604 021		
47	1	. Fjäderbricka .....	. Spring washer .....	S 955926-1	NMS 440/10	2 916 693 011		
48	1	. Mutter .....	. Nut .....	S 190718-7	WMU 10 L 11	1 103 300 003		
49	1	. Skyddsband .....	. Cover band .....	238802-3	LJVU 3 L 6	1 101 316 033		
50	1	. Skruv .....	. Screw .....	956062-4	NSR 5252/22	2 910 011 125		
51	1	. Mutter .....	. Nut .....	238803-1	NMU 2221/4	2 915 051 004		
		<b>LADDNINGSREGULATOR</b>	<b>CHARGING RELAY</b>					
60	1	. Laddningsregulator, kmpl.	. Charging relay, cpl. ....	238640-7	RS/VA 240/12/2	0 190 350 005		
51	2	. . Skruv (D+/61, D-) ...	. . Screw (D+/61, D-) ...	6605110-3	NSR 5597/9	2 910 003 148		
	1	. . Skruv (DF) .....	. . Screw (DF) .....	6605147-5	WSR 32 L 2	1 193 412 004		
	1	. . Skruv (B+) .....	. . Screw (B+) .....	956074-9	NSR 5254/13	2 910 021 150		
62	4	. Fjäderbricka .....	. Spring washer .....	955920-4	NMS 727/7	2 916 060 006		
63	1	. Skyddskåpa .....	. Protector case .....	<del>239366-8</del>	RSMK 11 L 2	1 190 582 030		
64	1	. Gummipackning .....	. Rubber packing .....	<del>239367-6</del>	RSPT 92 L 2	1 191 015 013		
65	1	. Skruv .....	. Screw .....	239368-4	WSR 113 L 1	1 193 429 000		
	1	Reparationssats (inneholder pos. nr 3, 5, 12, 26, 27, 31, 42-45, 47, 48)	Parts set (consisting of figs. nos. 3, 5, 12, 26, 27, 31, 42-45, 47, 48)	239430-2	G 65	9 101 240 026		
	1	Reparationssats (inneholder pos. nr 17-23, 27, 28).	Parts set (consisting of figs. nos. 17- 23, 27, 28).	273049-7	—	—		
	1	Reparationssats (inneholder pos. nr 8-10, 12, 14).	Parts set (consisting of figs. nos. 8-10, 12, 14).	273051-3	—	—		