

Grupp Group		3		P 180(B18)		VOLVO Reservdelskatalog Parts catalogue	
Sida Page	34	Utgåva Issue	7	Elledningar	Wiring		
Pos Fig.	Antal Qty.	Benämning	Description	Def. nr Part No.	Anmärkning Notes		
		Tändledningar .....	Ignition cables .....		Se sida 4		
1		Batteriledning, batteri-startmotor	Battery cable, battery-starter motor ...	192647-6	Vst I = 1050		
1		Batteriledning, batteri-startmotor	Battery cable, battery-starter motor ...	192214-5	Hst I = 570		
1		. Ledningssko, vid batteri ...	. Cable terminal, at battery .....	192196-4			
1		. Skruv .....	. Screw .....	105154-9			
1		. Mutter .....	. Nut .....	151205-2			
1		. Ledningssko, vid startmotor ...	. Cable terminal, at starter motor .....	956504-5			
1		Stomledning, batteri-kaross ...	Earth cable, battery-body .....	11417-3	Vst I = 150		
1		Stomledning, batteri-kaross ...	Earth cable, battery-body .....	11521-2	Hst I = 200		
1		. Ledningssko, vid batteri ...	. Cable terminal, at battery .....	954507-0			
1		. Skruv .....	. Bolt .....	105154-9			
1		. Mutter .....	. Nut .....	151205-2			
1		Stomledning, motor-ram .....	Earth cable, engine-frame .....	665142-6	1)		
1		Stomledning, motor-ram .....	Earth cable, engine-frame .....	190339-2	2) I = 200		
1		Stomledning, styrinrättning ...	Earth cable, steering gear .....	665143-4	Ch 6211-		
1		Ledningsknippe, bilvärmaremotor .	Cable harness, heater unit motor .....	668787-5	3)		
1		bilvärmaremotor .	heater unit motor .....	671622-9	4)		
1		bromsljuskontakt	brake lamp contact ...	670049-6	5)		
1		signalhorn ...	horn .....	671158-4	Ch 12500-23599		
1		signalhorn ...	horn .....	672811-7	Ch 23600-		
1		ratt-styrkolonn ..	steering wheel-steering ..				
			column .....		Se sida 12		
1		Ledning, huvud .....	Cable, main .....	668178-7	6) Vst	Ch-6210	
1		huvud .....	main .....	668179-5	7) Hst		
1		huvud .....	main .....	668181-1	Vst Ch 6001-23599		
1		huvud .....	main .....	668182-9	Hst Ch 6001-23599		
1		huvud .....	main .....	673953-6	<del>672809</del> Vst 1-kr Ch 23599-24124		
1		huvud för instrumentbräda och motorrum .....	main for instrument panel and engine housing .....	673312-5	Vst 2-kr Ch 24100- 673126		
1		huvud .....	main .....	672810-9	Hst Ch 24100-		
1		kaross .....	body .....	668180-3	Ch 6211-		
2		dörrströmbrytare ...	door switch .....	665848-8			
erf		Ledning, RK 0,75 mm <sup>2</sup> vit ...	Cable, RK 0.75 mm <sup>2</sup> white .....	954434-7			
erf		RK 1,0 mm <sup>2</sup> svart ...	RK 1.0 mm <sup>2</sup> black .....	954435-4			
erf		RK 1,5 mm <sup>2</sup> svart ...	RK 1.5 mm <sup>2</sup> black .....	954443-8			
erf		RK 1,5 mm <sup>2</sup> röd ...	RK 1.5 mm <sup>2</sup> red .....	954445-3			
erf		RK 1,5 mm <sup>2</sup> grön ...	RK 1.5 mm <sup>2</sup> green .....	954447-9			
erf		RK 1,5 mm <sup>2</sup> blå ...	RK 1.5 mm <sup>2</sup> blue .....	954448-7			
erf		RK 1,5 mm <sup>2</sup> vit ...	RK 1.5 mm <sup>2</sup> white .....	954450-3			
erf		RKK 1,5 mm <sup>2</sup> svart ...	RKK 1.5 mm <sup>2</sup> black .....	79072-5	<del>11765-</del>		
erf		Tändledning, RKKB 1,5 mm <sup>2</sup> röd .	Ignition cable, RKKB 1.5 mm <sup>2</sup> red ...	11925-5			
erf		Batteriledning, MK 25,0 mm <sup>2</sup> röd	Battery cable, MK 25.0 mm <sup>2</sup> red ....	954500-5			
erf		Plastslang, PVC svart .....	Plastic cable cover, PVC black ....	190198-2	d = 6, D = 7		
erf		PVC svart .....	PVC black .....	185500-6	d = 6, D = 8		
erf		PVC svart .....	PVC black .....	185501-4	d = 8, D = 9		
erf		PVC svart .....	PVC black .....	185507-1	d = 10, D = 11		

1. Ch 6211-10309.  
2. Ch 10310-.  
3. Ch-15173 excl 15037, 15041-15043, 15069-15082, 15091-15112, 15127-15142, 15145-15165, 15170-15171.  
4. Ch 15174-23599 incl 15037, 15041-15043, 15069-15082, 15091-15112, 15127-15142, 15145-15165, 15170-15171.  
5. Vst. -23599.  
Hst ch-9999.  
6. Ers av 1 st 668180-3. 1 st 668181-1.  
7. Ers av 1 st 668180-3. 1 st 668182-9.