



Fig. 25. Door components.

Fig.

<u>No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
	Blue liner, for rear shelf	94795 <sup>1)</sup>	1
	Red liner, for rear shelf	94843 <sup>1)</sup>	1
	Grey liner, for rear shelf	96748 <sup>1)</sup>	1
	Dark-blue liner, for rear shelf	655881 <sup>1)</sup>	1
	. Screw, self-tapping	106938	5
<u>DOORS</u>			
	Door, left, complete (unpainted less upholstery)	92501 <sup>x,2)</sup>	1
	Door, left, complete (unpainted less upholstery)	94976 <sup>x,3)</sup>	1
	Door, right, complete (unpainted less upholstery)	92502 <sup>x,2)</sup>	1
	Door, right, complete (unpainted less upholstery)	94977 <sup>x,3)</sup>	1
25- 1	. Bushing for lock cylinder (in left door)	90181	1
25- 2	. . Stop screw	14021	1
25- 3	. Hinge half in door	92784	4
25- 4	. Hinge half in body	92785	4
25- 5	. . Pin	91053	4
25- 6	. Screw for hinge half, in door	921622	16
25- 7	. . Base washer	11962	16
25- 8	. . Lock washer	951697	16
25- 9	. Screw for hinge in body (not included in complete door)	14374	12
25-10	. . Lock washer (not included in complete door)	17916	2
25-11	. Striking plate	91173	2
25-12	. . Shim	93934	2
25-13	. . Screw	14259	4
25-14	. <u>Lock</u> , left, complete	92786	1
	. Lock, right, complete	92787	1
25-15	. . Lock, left, complete	93894	1
	. . Lock, right, complete	93893	1
	. . . Spring	95666	2
25-16	. . Remote control, left, complete	93529	1
	. . Remote control, right, complete	93530	1
	. . . Spring	97073	2
25-17	. . Link	92788	2
25-18	. . . Rivet	93514	4
25-19	. . . . Washer, sprung	93513	4

1. Alternatives.

2. Up to chassis No. 20004.

3. From chassis No. 20005 onwards.

x. Included in complete body.

Body

<u>Fig.</u>	<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
25-20	. Screw for lock and remote control	950032	12
25-21	. . Lock washer	951694	12
25-22	<u>Guide</u> for remote control link	93670	2
25-23	. Leather spacer	93687	4
25-24	. Screw, self-tapping	106916	4
25-25	<u>Catch</u> , complete	92525 <sup>x)</sup>	2
25-26	. Catch	92527	2
25-27	. Spring	92528	2
25-28	Screw for catch	115880	4
25-29	. Lock washer	17898	4
25-30	<u>Window regulator</u> , left, complete	92584	1
	Window regulator, right, complete	92585	1
25-31	Screw for window elevator	115481	8
25-32	. Lock washer	951692	8
25-33	<u>Pulley</u> , upper, with retainer	92230	2
25-34	. Screw	115479	2
25-35	. . Base washer	120095	2
25-36	. . Lock washer	951694	2
25-37	Pulley, lower, with retainer	92357	2
25-38	. Screw	14678	2
25-39	. . Spring	92612	2
25-40	. . Nut	151224	4
25-41	Rubber cushion for window pane	82429	2
25-42	<u>Cable</u> with chain for window regulator	92586 <sup>1)</sup>	2
	Cable with chain for window regulator	94988 <sup>2)</sup>	2
	Anchorage for door upholstery	90492 <sup>3)</sup>	54
	Anchorage for door upholstery	95290 <sup>4)</sup>	54
	Moulding, straight, for door upholstery	94412	2
	Moulding, curved, for left door upholstery	96892	1
	Moulding, curved, for right door upholstery	96893	1
	. Anchorage	94890	8
	Moulding, outer, on door	94410	2
	. Anchorage (wire clip)	95384	10
	<u>Door stop</u> , consisting of:		
25-43	. Link with yoke bolt	95142 <sup>x)</sup>	2
25-44	. Catch housing	95100 <sup>x)</sup>	2
	1. Up to chassis No. 20004.		
	2. From chassis No. 20005 onwards.		
	3. Up to chassis No. 20104.		
	4. From chassis No. 20105 onwards.		
	x. Included in complete body.		

<u>Fig.</u>	<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
25-45	. Rubber cushion	95098 <sup>x)</sup>	2
25-46	. . Washer	95099 <sup>x)</sup>	2
25-47	. . Cotter pin	907856 <sup>x)</sup>	2
25-48	. Nut for yoke bolt	921782 <sup>x)</sup>	2
25-49	. . Base washer	18719 <sup>x)</sup>	2
25-50	. . Spring washer	906993 <sup>x)</sup>	2
25-51	. Screw for catch housing	115483 <sup>x)</sup>	4
25-52	. . Lock washer	951693 <sup>x)</sup>	4
<u>Lock cylinder, handles and window regulator handles for doors</u>			
25-53	<u>Lock cylinder</u> , complete, for left door	93897	1
25-54	. Sleeve with shaft	91989	1
25-55	. Lock cylinder with keys	93898	1
25-56	. . Key (state key number when ordering)	90771	2
25-57	<u>Door handle</u> , outer	94585	2
25-58	. Cotter pin	10678	2
25-59	<u>Door handle</u> , inner	94755	2
25-60	. Washer	94591	2
25-61	. Spring	90453	2
25-62	. Pin	92972	2
25-63	. Rubber ring	92395	2
25-64	<u>Window regulator handles</u>	94589	2
25-65	. Washer	94591	2
25-66	. Spring	90453	2
25-62	. Pin	92972	2
<u>Seal strips for doors</u>			
25-67	Seal strip, lower	92531	2
25-68	Seal strip on door flange	95645	2
<u>Windows and mouldings</u>			
	<u>Windscreen pane</u>	92533 <sup>1)</sup>	2
	Windscreen pane	95993 <sup>2)</sup>	2
	. Rubber seal	92517 <sup>1)</sup>	1
	. Rubber seal	96561 <sup>2)</sup>	1

1. Up to chassis No. 68955.
  2. From chassis No. 68956 onwards.
- x. Included in complete body.

Fig.

<u>No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
	. Rubber seal, inner, at centre pillar	92546 <sup>1)</sup>	1
	. Rubber seal, inner, at centre pillar	96353 <sup>2)</sup>	1
	. Rubber seal, outer, at centre pillar	92547 <sup>1)</sup>	1
	. Rubber seal, outer, at centre pillar	96352 <sup>2)</sup>	1
	. Moulding, inner, at centre pillar	92544 <sup>1)</sup>	1
	. Moulding, inner, at centre pillar	96168 <sup>2)</sup>	1
	. Moulding, outer, at centre pillar	92545 <sup>1)</sup>	1
	. Moulding, outer, at centre pillar	96349 <sup>3)</sup>	1
	. Moulding, outer, at centre pillar	96934 <sup>4)</sup>	1
	. . Screw	115885 <sup>1)</sup>	3
	. . Screw	115903 <sup>3)</sup>	3
	. . Screw	106989 <sup>4)</sup>	3
	. . . Nut	96935 <sup>4)</sup>	3
	. . . Washer	91944	3
25-69	<u>Window pane in door</u>	92535 <sup>5)</sup>	2
	Window pane in door	95010 <sup>6)</sup>	2
25-70	. Window regulator channel, left	92214	1
	. Window regulator channel, right	92215	1
25-71	. . Filler strip, cork	90693	x)
25-72	. . Filler strip, rubber	91986	x)
25-73	. Clamp for flange on cable	92590	2
25-74	. . Screw	115479	2
25-75	. . . Lock washer	951696	2
25-76	. Retainer for forward guide channel (left door)	92550 <sup>5)</sup>	1
	. Retainer for forward guide channel (right door)	92551 <sup>5)</sup>	1
25-77	. . Screw, self-tapping, upper, in door	13171	2
25-78	. . . Washer	120085	2
	. Retainer for forward guide channel (left door)	94992 <sup>6)</sup>	1
	. Retainer for forward guide channel (right door)	94993 <sup>6)</sup>	1
	. . Screw, self-tapping, upper, in door	106924	2
	. . . Washer	120085	2
25-79	. Screw for retainer, lower, in door	115479	4
25-80	. . Washer	120095	4
25-81	. . Lock washer	951696	4

1. Up to chassis No. 68955.

2. From chassis No. 68956 onwards.

3. For chassis Nos. 68956-106140, 106142-106825.

4. From chassis No. 106826 onwards as well as No. 106141.

5. Up to chassis No. 20004.

6. From chassis No. 20005 onwards.

x. State required length.

<u>Fig.</u>	<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
25-82	<u>Window guide channel</u> , forward, for window pane	92379 <sup>1)</sup>	2
	Window guide channel, forward, for window pane	95008 <sup>2)</sup>	2
25-83	Window guide channel, rear, for window pane	92380	2
	. Screw, self-tapping	13165	4
25-84	Retainer for rear rubber seal strip (at ventilator window)	92552 <sup>1)</sup>	2
	Retainer for rear rubber seal strip (at ventilator window)	95061 <sup>2)</sup>	2
25-85	Retainer for rear guide channel	93819	2
25-86	. Screw	115479	4
25-87	. . Washer	120095	4
25-88	. . Lock washer	951696	4
25-89	Seal strip, outer left and inner right, for door window pane	92941 <sup>1)</sup>	2
	Seal strip, outer right and inner left, for door window pane	92942 <sup>1)</sup>	2
	Seal strip, outer left and inner right, for door window pane	95006 <sup>2)</sup>	2
	Seal strip, outer right and inner left, for door window pane	95007 <sup>2)</sup>	2
25-90	Screw, self-tapping, for outer seal strip	14932	28
25-91	Sponge rubber strip for door window pane	90635 <sup>1)</sup>	x)
	Sponge rubber strip for door window pane	95136 <sup>2)</sup>	2
25-92	Sponge rubber strip for door window pane	93503	x)
	Filler strip, thickness = 0.085"	91985 <sup>3)</sup>	x)
	Filler strip, thickness = 0.095"	92384 <sup>3)</sup>	x)
	<u>Window bow</u> , left	92833 <sup>1)</sup>	1
	Window bow, right	92834 <sup>1)</sup>	1
	Window bow, left	95012 <sup>2)</sup>	1
	Window bow, right	95013 <sup>2)</sup>	1
	. Screw, self-tapping, length = 10 mm	13173	4
	. Screw, self-tapping, length = 22 mm	14892	22
	. . Washer	91944 <sup>1)</sup>	22

1. Up to chassis No. 20004.

2. From chassis No. 20005 onwards.

3. Alternatives.

x. State required length.

<u>Fig.</u>	<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
25-93	<u>Ventilator window</u> , complete, with lens, chromed frame, anchorages, shaft and fittings for handles		
	. Left	94921 <sup>1)</sup>	1
	. Right	94922 <sup>1)</sup>	1
	. Left	95125 <sup>2)</sup>	1
	. Right	95126 <sup>2)</sup>	1
	. Left	96714 <sup>3)</sup>	1
	. Right	96715 <sup>3)</sup>	1
25-94	. <u>Handles for ventilator windows</u> , left	94300 <sup>4)</sup>	1
	right	94301 <sup>4)</sup>	1
	left	95066 <sup>5)</sup>	1
	right	95067 <sup>5)</sup>	1
25-95	. . Catch	94305 <sup>4)</sup>	2
	. . Catch	95068 <sup>5)</sup>	2
25-96	. . Spring	94341	2
25-97	. Washer, sprung	120164	4
25-98	. Slotted pin for handle	133023	2
25-99	. Locking device for ventilator window	91895	2
25-100	. . Rivet	91862	4
	. Cap, upper, for pin on left ventilator window	92821 <sup>1)</sup>	1
	. Cap, upper, for pin on right ventilator window	92822 <sup>1)</sup>	1
	. . Screw, self-tapping	13173	4
25-101	. <u>Hinge half</u> for left ventilator window (in door)	95020 <sup>6)</sup>	1
	. Hinge half for right ventilator window (in door)	95021 <sup>6)</sup>	1
25-102	. . Rivet	91862	4
25-103	. Rivet, hinge half in door - hinge half in ventilator window	17455	2
25-104	. . Washer	120151	4

1. Up to chassis No. 20004.
2. Chassis Nos. 20005-82564.
3. From chassis No. 82565 onwards.
4. Up to chassis No. 28004.
5. From chassis No. 28005 onwards.
6. From chassis No. 20005 onwards.

		<u>Body</u>	
<u>Fig.</u>			
<u>No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
25-105	. Cap, lower, for pin on ventilator window	92818	2
25-106	. . Spring	91886	4
25-107	. . Bolt	105205	4
25-108	. . . Nut	151215	4
25-109	. <u>Rubber seal</u> , forward, for left ventilator window	92561 <sup>1)</sup>	1
	. Rubber seal, forward, for right ventilator window	92562 <sup>1)</sup>	1
	. Rubber seal, forward, for left ventilator window	95004 <sup>2)</sup>	1
	. Rubber seal, forward, for right ventilator window	95005 <sup>2)</sup>	1
25-110	Rubber seal, rear, for ventilator window	92563 <sup>1)</sup>	2
	Rubber seal, rear, for ventilator window	95024 <sup>2)</sup>	2
	Filler strip for ventilator window, length = 100 mm	94045	2
	<u>Quarter window pane</u>	92537	2
	. Rubber seal	92518	2
	<u>Rear window pane</u>	92534 <sup>3)</sup>	2
	Rear window pane	95956 <sup>4)</sup>	1
	. Rubber seal	92515 <sup>3)</sup>	2
	. Rubber seal	95962 <sup>4)</sup>	1
	<u>Mouldings for P 44404</u>		
	Moulding, outer, on door	94410	2
	Moulding on mudguard and body side	94409	6
	. Anchorage (screw with washer)	94441	12
	. . Nut	906574	12
	. . Spring washer	906985	12
	. Anchorage (wire clip)	95384	28

1. Up to chassis No. 20004.
2. From chassis No. 20005 onwards.
3. Up to chassis No. 68955.
4. From chassis No. 68956 onwards.