

<u>Fig. No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
6-29	<u>Thermostat</u>	403336	1
6-30	Hose, water pump - water outlet housing	13911	1
6-31	Elbow bend for water inlet (on cylinder block)	403166 ¹⁾	1
	Elbow bend for water inlet (on cylinder block)	403542 ²⁾	1
6-32	. Gasket	403163	1
6-33	. Bolt	902280	2
6-34	. . Spring washer	906990	2
	. Plug for heater line aperture, early production, taper thread W 3/8" - 19/1"	16317	1
	. Plug for heater line aperture, late production, taper thread NPTF 3/8" - 18/1"	180741	1
6-35	<u>Radiator hose</u> , upper, length = 90 mm	87994	1
6-36	Radiator hose, lower, radiator unit - engine, early production, length = 350 mm	88131	1
	Radiator hose, lower, radiator unit - engine, late production, length = 255 mm	89684	1
6-37	. Hose clamp	18976	4
6-38	<u>Radiator unit</u>	28471	1
6-39	. Cap for radiator unit, alt. 1	88464	1
	. Cap for radiator unit, alt. 2 (pressure cap)	87842	1
6-40	. Drain cock on radiator unit	87502	1
6-41	Bolt for radiator unit	902251	4
6-42	. Nut	151215	4
6-43	. Base washer	11961	4
6-44	. Spring washer	906987	4
6-45	<u>Radiator blind</u>	89757	1
	. Screw, early production	115474	2
	. . Base washer, early production	120085	2
6-46	. Screw (self-threading), late production	105821	2
6-47	. . Base washer, late production	120085	2
6-48	. . Nut, late production	95258	2
6-49	Chain for radiator blind	88436	1
6-50	. Ring for chain	88495	1
6-51	Chain lock	88434	1
6-52	. Screw	107400	2

1. Fitted in conjunction with radiator hose No. 88131. Replaces early production elbow bend without heater line aperture. From spare parts point of view when the early production elbow bend is replaced 1 seal plug must be fitted simultaneously.

2. Fitted in conjunction with radiator hose No. 89684.

Electrical equipment
Distributor, Auto-Lite
72944

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
<u>ELECTRICAL EQUIPMENT</u>		
<u>Distributor, complete, Auto-Lite: IAT-4006</u>	72944 ¹⁾	1
. Housing, complete, IAT-2040	72987	1
. . Bushing, IG-579 A	18183	2
. Retainer spring for cover, IGB-1007	72989	2
. . Screw (also for contact plate)	950009	2
. . . Spring washer	906983	2
. Grease cup, X-1590	72990	1
. Lubricating felt, IGS-117	73103	1
. Screw for cable connection, No. 10-32, length = 7/8", X-3012	106704	1
. . Insulating plate, IAT-6	73102	1
. . Insulating bushing, IAT-7	18175	1
. . Insulating washer, IGL-9A	25117	1
. . Nut	151214	2
. . . Base washer, 8X-183 A	18734	1
. . . Spring washer	906985	2
. Drive shaft, IGS-1053 RC	72991	1
. . Adjuster washer, hole diam. = 13,6 mm, IAO-10	72992	1
. . Adjuster washer, hole diam. = 14,9 mm, IAO-11	72993	1
. Weight for setting, IG-1456	72785	2
. . Spring, IGC-42 KS	72786	1 set
. Spacer ring for breaker cam, IGS-99	72825	1
. Breaker cam, IGC-1132 RL	72994	1
. . Spring, IGT-70	72746	1
. Lock spring for breaker cam, IG-680	72747	1
. Lubricating felt, IGH-28	72748	1
. <u>Contact plate, complete, IAT-2004 R</u>	72995	1
. . Contact plate, IAT-2004 RS	72996	1
. . . Contact retainer with contact arm, IGW-3028 BS	72997	1
. . . Contact line (earth), IAT-14	72998	1
. . . Contact line, IAT-24 R	72999	1
. . . . Screw No. 8-32, length = 3/16"	950007	1
. . . . Screw No. 8-32, length = 1/4"	950008	1
. Spring washer	906983	1
. Base washer, SSB-38	120007	1
1. Up to engine No. 94899 except Nos. 94538-94633.		

Electrical equipment
Distributor, Auto-Lite
72944

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
. Screw No. 6-32, length = 3/16"	950002	1
. Base washer, IGE-15	120006	1
. . Condensor, IAT-3076 R	72986	1
. . . Screw No. 6-32, length = 5/32", 8X - 1546	950000	1
. . . . Spring washer, 12 X - 194	17899	1
. Distributor rotor, IAT-1016	72971	1
. Distributor cap, complete, IAT-1041	72970	1
. Coupling fork on drive shaft, IG-644 A	72796	1
. Slotted pin	17230	1
. Adjuster washer, thickness = 0,7 mm, IG-90	120005	1
. Adjuster washer, thickness = 1,6 mm, IG-90 A	120195	1
. <u>Vacuum governor</u> , complete, IAT-2023 RM	73100	1
. . Spring, VC-77	72798	1
. . Shim, thickness = 0.010", VC-46 A	120008	x)
. . Shim, thickness = 0.032", VC-46	120009	x)
. . Shim, thickness = 0.060", VC-46 B	120010	x)
. . . Screw connection, VC-15	180011	1
. . . . Copper washer, VC-14	11996	1
. . Lock ring for vacuum governor lever, IGS-17	73104	1
. . Screw for vacuum governor, 8 X - 872	115264	2
. . . Lock washer	951693	2
. Control arm for distributor, IAT-42	73101	1
. . Bolt, 8 X - 86	101053	1
. . . Spring washer	906987	1
. . . Base washer	11961	1
Rubber seal ring for distributor No. 72944	403437	1
Bolt, control arm-cylinder block, for distributor No. 72944	902279	1
. Spring washer	906990	1

x. Order as required.

Electrical equipment

Distributor, Auto-Lite

72570

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
<u>Distributor</u> , complete, Auto-Lite: IGS-4210	72570 ¹⁾	1
. Housing, complete, IGS-2163	72782	1
. . Bushing	18183	2
. . Retainer spring for cap, IG-694	72737	2
. . . Pin	17450	2
. . Grease cup	10676	1
. Drive shaft, IGC-1130 RB	72784	1
. Weight for setting, IG-1456	72785	2
. . Spring	72786	1 set
. Spacer ring for breaker cam, IGS-99	72825	1
. <u>Breaker cam</u> , IGC-1132 RB	72801	1
. . Spring, IGT-70	72746	1
. Lock spring for breaker cam, IG-680	72747	1
. Lubricating felt, IGH-28	72748	1
. <u>Contact plate</u> , complete, IGS-3004 P	72787	1
. . Lower section, IGS-1004 D	72788	1
. . Upper section, with bearing, IGS-1082 R	72789	1
. . . Retainer for contact arm, IGS-1086 RM	72790	1
. . . . Screw	950007	1
. Base washer	120007	1
. . Contact arm, complete, IGP-3028	72753	1
. . . Spring, IGP-30	72754	1
. . Contact retainer, complete, with contact arm, IGP-3028 ES	72791	1 set
. . Clamp for contact arm, IA-131	72774	1
. . . Screw	950002	1
. . . . Base washer	120006	1
. . Condensor, IG-2671 F	72792	1
. . . Screw	950000	1
. . . . Spring washer	17899	1
. . Contact line, complete, with cable terminals, IGS-59 A	72793	1
. . Contact line, complete, with cable terminals, IGS-89	72777	1
. . . Screw	950000	3
. . . . Spring washer	17899	3
. Screw for contact plate, 8X-870	61940	2
. Spring clamp, IGS-18	72799	2
1. Engine Nos. 94538-94633, 94900 -95185, 96634-96828.		

Electrical equipment
Distributor, Auto-Lite
72570

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
. . Lock washer	951693	2
. Screw for cable connection	115264	1
. . Spring washer	906985	1
. Rubber sleeve, IGS-34	72778	1
. <u>Distributor rotor</u> , IG-1657 R	72794	1
. Distributor cap, complete, IG-1324	72795	1
. . Carbon brush, IG-514	72759	1
. . Spring, IG-515 A	72760	1
. <u>Coupling fork</u> on drive shaft, IG-644 A	72796	1
. . Slotted pin	17230	1
. . Adjuster washer	120005	1
. <u>Vacuum governor</u> , complete, VC-3082 RLS	72797	1
. . Spring, VC-77	72798	1
. . Shim, thickness = 0.010"	120008	x)
. . Shim, thickness = 0.032"	120009	x)
. . Shim, thickness = 0.060"	120010	x)
. . Screw connection	180011	1
. . . Copper washer	11996	1
. Screw for vacuum governor	115264	2
. . Lock washer	11933	2
Rubber seal ring for distributor No. 72570	48394	1
<u>Anchorage plate</u> , complete, for distributor No. 72570	403291	1
. Clamp screw	115089	1
. . Nut	151215	1
Bolt, anchorage plate - cylinder block, for distributor No. 72570	902279	2
. Spring washer	906990	2

x. Order as required.

Electrical equipment

Distributor, Bosch

76853

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
<u>Distributor</u> , complete, Bosch: VJU 4 BR 9	76853 ¹⁾	1
. Housing, complete, ZGE 154 Z 76	233261	1
. . Bushing, upper, WMB 50 Z 4	233262	1
. . Bushing, lower, WMB 50 Z 3	233263	1
. . Lubricating wick, WDO 402 Z 15	233264	1
. Retainer spring for cap, ZBF 75 Z 4	77658	2
. . Clamp without guide projection, ZBE 40 Z 4	77659	1
. . Clamp with guide projection, ZBE 40 Z 5	77660	1
. . . Screw (also for breaker plate)	14114	2
. . . . Spring washer	906983	2
. Grease cup, WOL 1/1	35028	1
. Condensor, ZKO 29 Z 65	77661	1
. . Screw	14116	2
. . . Spring washer	906983	2
. <u>Shaft</u> with tensioner stay, ZAC 70 Z 482	233265	1
. . Tensioner stay, ZBE 59/1	48316	1
. . . Screw, WSR 113/1	25503	2
. . . . Base washer, NMS 7/2	35431	2
. . . . Spring washer	906983	2
. Weight for setting, ZPT 214 Z 30	233266	2
. . Damping plate under weight, ZPT 410 Z 1	76973	1
. . Insulating washer under weight, WNS 11 Z 8	82387	2
. . Lock spring for weight, WMR 118 Z 1	76928	2
. Spring for setting, WSF 89 Z 40	233267	2
. Fibre washer on shaft, WNS 31/3	25929	2
. Shim, thickness = 0,1 mm, WMS 101/12	25930	x)
. <u>Breaker cam</u> , ZNC 46 Z 386	233268	1
. . Lubricating felt, WDO 401/13	48401	1
. . Adjuster washer, thickness = 1,0 mm, WMS 401/26	48326	x)
. . Adjuster washer, thickness = 0,5 mm, WMS 401/27	48327	x)

1. From engine No. 96829 onwards as well as Nos. 95186-96633.

x. Order as required.

Electrical equipment

Distributor, Bosch

76853

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
. . Adjuster washer, thickness = 0,3 mm, WMS 401 Z 69	120760	x)
. . Insulating washer, WMS 416/8	48328	1
. Coupling on shaft, ZKH 15 Z 27	76976	1
. . Slotted pin	907186	1
. <u>Breaker plate</u> , complete, ZUB 17 Z 25	77664	1
. . Contact plate, ZKT 67/1	77665	1
. . . Screw, WSR 400/32	77543	1
. . . Eccentric bolt, WBO 277/1	25936	1
. . Contact arm with cable, ZUH 9/8	77667	1
. . . Shim, thickness = 0,2 mm, WMS 23/1	48331	x)
. . . Shim, thickness = 0,1 mm, WMS 23/3	48332	x)
. . . Shim, thickness = 0,05 mm, WMS 23/4	48333	x)
. . . Lock spring, WMR 20/2	77683	1
. . Ball on breaker plate, NKU 1/11	77692	1
. . . Lock washer for ball, ZBF 129/1	77668	1
. . . . Screw	115001	1
. Spring washer	906981	1
. Angle with pin, for vacuum governor, ZBF 167/1	77669	1
. . Screw	14116	1
. . . Spring washer	906983	1
. Screw for breaker plate	14114	2
. . Spring washer	906983	2
. Screw for condensor connection	105215	1
. . Insulating washer	120213	2
. . Base washer, NMS 8/2	25195	4
. . Nut	151207	2
. . . Spring washer	906983	2
. <u>Distributor rotor</u> , ZVT 53 Z 9	76977	1
. Distributor cap, complete, ZVS 75 Z 6	233260	1
. . Carbon brush with spring, NSK 2/1	60799	1
. <u>Vacuum governor</u> , ZSV 22 Z 17	233269	1
. . Screw	14116	2
. . . Spring washer	906983	2
. Control arm, complete, ZHE 47 Z 5	233270	1
. . Clamp screw	902258	1
. . . Nut	906575	1

x. Order as required.

Electrical equipment

Distributor, Bosch

76853

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
Rubber seal ring for distributor No. 76853	48394	1
Bolt, control arm-cylinder block, for distributor No. 76853	902278	1
. Spring washer	906990	1
<u>Vacuum line for distributor; see page 63</u>		
<u>Ignition coil, complete, early production Auto-Lite: CR 4601</u>	88475 ¹⁾	1
. Ignition coil	N.S.S.	
. Ignition switch with cable	N.S.S.	
. Nut	151214	7
. . Spring washer	906985	7

1. Replaced by 1 ignition coil No. 76804, 1 lock cylinder No. 76805, 2 screws No. 107410 and 2 base washers No. 18709.