

Electrical equipment

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
<u>ELECTRICAL CABLES</u>		
<u>Ignition cable</u> , complete, for 1st and 2nd cylinders	17535	2
Ignition cable, complete, for 3rd cylinder	17533	1
Ignition cable, complete, for 4th cylinder	17534	1
. Clamp cable terminal at distributor cap	11569	4
. Tubular cable terminal at sparking plug	48715	4
Rubber protector for ignition cables	20366	4
<u>High tension cable</u> , complete, distributor - ignition coil	655986	1
. Cable	11925	x)
. Clamp cable terminal	11569	2
Rubber protector for high tension cable	20366	2
<u>Low tension cable</u> , complete, distributor - ignition coil	88613	1
. Cable terminal	11423	2
. Rubber protector	83403	2
Earthing cable for engine	11525	1
. Screw	902302	1
. . Base washer	11964	1
. . Spring washer	906993	1
Earthing cable, complete, for battery	11524	1
. Screw for cable terminal	105154	1
. . Nut	151205	1
<u>Starter motor cable</u> , complete	11830	1
. Cable, red	11580	x)
. Cable terminal at battery	13748	1
. . Screw	105154	1
. . . Nut	151205	1
. Cable terminal at starter motor	11403	1
. . Protector sleeve	140127	1

x. State required length.

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
Cable harness, complete, under instrument panel	88901 ¹⁾	1
. Cable terminal 0,75 - 2,5 mm ² with 3,5 mm aperture	13753	4
0,75 - 2,5 mm ² with 5,3 mm aperture	11423	11
4 - 6 mm ² with 5,3 mm aperture	11409	6
4 - 6 mm ² with 8,4 mm aperture	11410	1
. Bulb socket	82159	1
. . Spring	82385	1
. . Bushing	82386	1
. . Washer	82387	1
. Connector, 6-point	88838	1
. . Sleeve for connector	88841	1
Cable harness, complete, under instrument panel	89478 ²⁾	1
Cable harness, complete, under instrument panel	89761 ³⁾	1
Cable harness, complete, under instrument panel	651791 ⁴⁾	1
. Cable terminal, 0,75 - 2,5 mm ² with 3,5 mm aperture	13753	5
0,75 - 2,5 mm ² with 4,0 mm aperture	11576	1
0,75 - 2,5 mm ² with 5,3 mm aperture	11423	9
4 - 6 mm ² with 5,3 mm aperture	11409	5
4 - 6 mm ² with 8,4 mm aperture	11410	1
. Bulb socket	82159	1
. . Spring	82385	1
. . Bushing	82386	1
. . Washer	82387	1
Cable harness, complete, for automatic blinker unit warning lamp	89376 ⁵⁾	1
. Bulb socket	82159	1
. . Spring	82385	1
. . Bushing	82386	1
. . Washer	82387	1
Cable, complete, for blinker relay	89450 ⁵⁾	1
. Cable terminal	13753	1

1. Up to chassis Nos. 28005-37004
2. For chassis Nos. 37005-68955.
3. For chassis Nos. 68956-108313.
4. From chassis No. 108314 onwards.
5. From chassis No. 56221 onwards.

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
Cable harness, complete, relay - dynamo	88798	1
. Cable terminal, 0,75 - 2,5 mm ² with 5,3 mm aperture	11423	2
4 - 6 mm ² with 5,3 mm aperture	11409	1
4 - 6 mm ² with 6,7 mm aperture	11405	1
Cable harness for left tail light	88800 ¹⁾	1
Cable harness for right tail light	88801 ¹⁾	1
Cable harness, complete, for left tail light	89836 ²⁾	1
Cable harness, complete, for right tail light	89837 ²⁾	1
. Bulb socket	96690	2
. . Spring	96692	2
. . Washer	96691	2
<u>Cables</u>		
1,5 mm ² red	11730	x)
1,5 mm ² black	11750	x)
1,5 mm ² blue	11705	x)
2,5 mm ² red	11660	x)
2,5 mm ² black	11770	x)
2,5 mm ² green	11685	x)
4 mm ² red	11630	x)
6 mm ² red	11640	x)
Cable terminals, 0,75 - 2,5 mm ² with 3,5 mm aperture	13753	x)
0,75 - 2,5 mm ² with 5,3 mm aperture	11423	x)
4 - 6 mm ² with 5,3 mm aperture	11409	x)
4 - 6 mm ² with 8,4 mm aperture	11410	x)
Clamp for fuel gauge cable	951189	x)
<u>Rubber bushings and cable protectors</u>		
Rubber bushing for cable		
ext. diam. = 18 mm, int. diam. = 6 mm	69153	x)
ext. diam. = 18 mm, int. diam. = 8 mm	43138	x)
ext. diam. = 22 mm	91395	x)
ext. diam. = 30 mm	88273	x)
ext. diam. = 36 mm	87841	x)
ext. diam. = 40 mm	66089	x)

1. Up to chassis No. 68955.

2. From chassis No. 68956 onwards.

x. State required length.