

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
. Spring washer	906985	2
Socket for bulb	30084	1
. Bulb	182007	1
Rubber cover for socket	88674	1
<u>Stop and tail light, left and right, complete, consisting of:</u>		
. Housing, left	87978 <sup>1)</sup>	1
. Housing, right	87979 <sup>1)</sup>	1
. . Lens	94101 <sup>1)</sup>	2
. . . Gasket	87722 <sup>1)</sup>	2
. . . Clamp	87721 <sup>1)</sup>	4
. . . . Screw, self-tapping	14923 <sup>1)</sup>	4
. Screw for housing	115875 <sup>1)</sup>	2
. Retainer, complete, for housing and bulb	87714 <sup>2)</sup>	1
. . Screw for cable connection	915590	4
. Retainer, complete, for housing and bulb	89045 <sup>3)</sup>	2
. . Screw for cable connection	14940	4
. Rubber spacer for retainer	87723 <sup>1)</sup>	2
. Nut for retainer	151215 <sup>1)</sup>	4
. . Base washer	11961 <sup>1)</sup>	4
. . Lock washer	951696 <sup>1)</sup>	4
. Bulb (in conjunction with retainer No. 87714)	19924	2
. Bulb (in conjunction with retainer No. 89045)	19897	2
Stop and tail light, left, complete, Bosch: B 87	76881 <sup>4)</sup>	1
Stop and tail light, right, complete, Bosch: B 86	76882 <sup>4)</sup>	1
. Housing, left, B 87/11	76844	1
. . Rubber base, B 87/10	76846	1
. Housing, right, B 86/11	76845	1
. . Rubber base, B 86/10	76847	1
Bulb for stop and tail light	19897	2
Nut for stop and tail light	120403 <sup>4)</sup>	6

1. Up to chassis No. 68955.

2. Up to chassis No. 26686. Replaced by 1 retainer No. 89045, 1 bulb No. 19897 and 1 connector No. 182010.

3. For chassis Nos. 26687-68955.

4. From chassis No. 68956 onwards.

Electrical equipment

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
<u>Instrument lighting</u>		
Bulb for instrument lighting	11448	2
Bulb for headlight warning lamp	11497	1
Bulb for directional indicator warning lamp	11448 <sup>1)</sup>	2
Bulb for directional indicator warning lamp	11497 <sup>2)</sup>	2
Socket for bulb	82159	3
. Spring	82385	3
. Bushing	82386	3
. Washer	82387	3

1. Up to chassis No. 108313.

2. From chassis No. 108314 onwards.