

<u>Description</u>	<u>Tools</u>	
	<u>Part No.</u>	<u>Qty.</u>
<u>TOOLS</u>		
Jack	210036	1
Plate showing jack positions	88728	1
Spanner for jack (also for wheel bolts)	210037	1
Hammer	751	1
Plier	754	1
Adjustable spanner	755	1
Set of screw drivers	210074	1
Screw driver	760	1
Sparking plug spanner, early production, intended for 10 mm sparking plugs	210004	1
Sparking plug spanner, late production, intended for 14 mm sparking plugs	190488	1
Tool bag	81757	1
Instruction book case	655733	1
<u>SETS OF SPARE PARTS</u>		
<u>Set of gaskets for engine renovation</u>	54325	
Consisting of gaskets for:		
. Crankshaft (felt)	13236	2
. Breather cap	16340	1
. Timing gear casing (felt ring)	19236	1
. Breather pipe	60924	1
. Fuel pump	61830	2
. Forward exhaust pipe	87765	1
. Oil sump	403017	1
. Side cover for push rods	403052	2
. Seal plate, forward	403074	1
. Timing gear casing	403075	1
. Valve cover	403087	1
. Seal flange for rear crankshaft bearing (wooden fillet)	403090	2
. Housing for water pump	403105	1
. Thermostat housing	403119	1
. Flange with delivery pipe, from oil pump	403122	1
. Elbow bend for water outlet	403161	1
. Elbow bend for water inlet	403163	1
. Carburetter	403288	1
. Seal flange at rear crankshaft bearing	403299	1
. Exhaust manifold	403454	1
. Induction and exhaust manifolds	403455	2
. Cylinder head	403598	1

<u>Description</u>	<u>Tools</u>	
	<u>Sets of spare parts</u>	
	<u>Part No.</u>	<u>Qty.</u>
<u>Set of gaskets for engine decarbonizing</u>	54327	
Consisting of gaskets for:		
. Forward exhaust pipe	87765	1
. Valve cover	403087	1
. Carburetter	403288	1
. Exhaust manifold	403454	1
. Induction and exhaust manifolds	403455	2
. Cylinder head	403471	1
<u>Set of gaskets for induction and exhaust manifolds</u>		
Consisting of gaskets for:		
. Forward exhaust pipe	87765	1
. Exhaust manifold	403454	1
. Induction and exhaust manifolds	403455	2
<u>Set of pistons</u>		
Consisting of:		
. 4 pistons		
. 4 gudgeon pins		
. 8 lock rings		
. as follows:		
. Standard size	54638	
. 0.010" oversize	54639	
. 0.020" oversize	54640	
. 0.030" oversize	54641	
. 0.040" oversize	54642	
. 0.050" oversize	54643	
<u>Set of piston rings</u>		
Consisting of:		
. 4 piston rings, upper		
. 4 piston rings, lower		
. 4 oil control rings		
. as follows:		
. Standard size	54490	
. 0.0025" oversize	54491	
. 0.010" oversize	54492	
. 0.020" oversize	54493	
. 0.030" oversize	54494	
. 0.040" oversize	54495	
. 0.050" oversize	54496	

Tools  
Sets of spare parts

<u>Description</u>	<u>Part No.</u>	<u>Qty.</u>
<u>Set of spare parts for water pump</u>	54609	
Consisting of:		
. Ball bearing	11136	2
. Lock pin	43019	1
. Slinger ring	70913	1
. Gasket for housing	403105	1
. Shaft	403352	1
. Impeller	403476	1
. Rubber gasket	412338	1
<u>Set of ignition cables</u>	54412	
Consisting of:		
. Ignition cable for 1st and 2nd cylinders	17535	2
. Ignition cable for 3rd cylinder	17533	1
. Ignition cable for 4th cylinder	17534	1
. High tension cable, distributor - ignition coil	88955	1
. Rubber protector for cables	20366	6
<u>Set of lock washers</u>	54092	
Consisting of:		
. <u>Part No.</u> <u>Qty.</u> <u>Part No.</u> <u>Qty.</u>		
15181     2       120320     4		
15232     3       403039     1		
15252     2       403181     1		
15269     2		
<u>King pin set</u>	54011 <sup>1)</sup>	
Consisting of:		
. Bushing	18148	4
. Ball bearing	19597	2
. Key	80856	2
. Seal washer	83414	4
. King pin	87019	2
. Shim, thickness = 0,10 mm	87209	6
. Shim, thickness = 0,35 mm	87210	4
. Dust cover, early production	87282	2
. Dust cover, late production	89369	2
. Washer	87401	2
. Castellated nut, early production	153001	2
. Castellated nut, late production	153034	2
. Cotter pin, early production	907833	2
. Cotter pin, late production	907825	2

1. Up to chassis No. 20004.

<u>Description</u>	<u>Tools</u>	
	<u>Sets of spare parts</u>	
	<u>Part No.</u>	<u>Qty.</u>
<u>King pin set</u>	54017 <sup>1)</sup>	
Consisting of:		
. Bushing	18262	4
. Ball bearing	19597	2
. Key	80856	2
. Seal washer	83414	4
. King pin	88649	2
. Shim, thickness = 0,10 mm	87209	6
. Shim, thickness = 0,35 mm	87210	4
. Dust cover, early production	87282	2
. Dust cover, late production	89369	2
. Washer, early production	87401	2
. Castellated nut, early production	153001	2
. Castellated nut, late production	190573	2
. Cotter pin, early production	907833	2
. Cotter pin, late production	907825	2
<u>Set of brake linings</u>	54461 <sup>2)</sup>	
Consisting of:		
. Rivet	17433	72
. Adjuster pin	87913	4
. Brake lining for forward brake shoe	87929	4
. Brake lining for rear brake shoe	87930	4
. Adjuster	210030	1
<u>Set of brake linings</u>	54656 <sup>3)</sup>	
Consisting of:		
. Adjuster pin	87913	4
. Brake lining for forward brake shoe	88168	4
. Brake lining for rear brake shoe	88169	4
. Adjuster	210030	1
<u>Clutch lining set</u>	54033	
Consisting of:		
. Clutch lining	N.S.S.	
. Rivet	17435	16

1. From chassis No. 20005 onwards.

2. For cars with riveted linings.

3. For cars with bonded linings.

<u>Description</u>	<u>Tools</u>	
	<u>Sets of spare parts</u>	
	<u>Part No.</u>	<u>Qty.</u>
<u>Set of spare parts for steering idler arm</u>	54923 <sup>1)</sup>	
Consisting of:		
. Nut	951201	1
. Lubricator	914169	1
. Lock washer	951699	1
. Bushing	18133	2
. Dust cover	87158	2
. Dust cover	87282	2
. Washer	87401	2
. Spacer sleeve	87526	1
. Bolt	100264	1
. Castellated nut	153001	2
. Cotter pin	907833	2
<u>Set of spare parts for steering idler arm</u>	54927 <sup>2)</sup>	
Consisting of:		
. Nut	951201	1
. Cotter pin	907825	2
. Lubricator	951739	1
. Lock washer	951699	1
. Bushing	18133	2
. Dust cover	87158	2
. Spacer sleeve	87526	2
. Dust cover	89369	2
. Bolt	100264	1
. Castellated nut	190573	2
<u>Set of spare parts for steering gear rebushing</u>	54924 <sup>3)</sup>	
Consisting of:		
. Spring washer	906993	5
. Felt ring	11335	1
. Copper gasket	951702	2
. Cotter pin	907860	1
. Bushing	18280	2
. Gasket	67423	1
. Shim	67426	1
. Oil seal	114401	1

1. Up to chassis No. 37004.

2. From chassis No. 37005 onwards.

3. Up to chassis No. 80522 except Nos. 76001-76092, 76094-80521.

<u>Description</u>	<u>Tools</u>	
	<u>Part No.</u>	<u>Qty.</u>
<u>Set of spare parts for steering gear rebushing</u>	54926 <sup>1)</sup>	
Consisting of:		
. Castellated nut	10523	1
. Spring washer	906990	3
. Cotter pin	907861	1
. Bushing	85601	1
. Bushing	85602	1
. Bushing	85604	1
. Gasket	85605	1
. Shim, thickness = 0,1 mm	85607	1
. Seal ring	114271	1
. Felt ring	122042	1
<u>Set of spare parts for control arm bearing, upper, outer</u>	54920 <sup>2)</sup>	
Set of spare parts for control arm bearing, upper, outer	54925 <sup>3)</sup>	
Consisting of:		
. Lubricator	951739	1
. Nut	17620	1
. Lock washer	18872	2
. Bolt	87020	1
. Eccentric bushing for set No. 54920	87023	1
. Eccentric bushing for set No. 54925	89834	2
. Rubber seal	88147	2
<u>Set of spare parts for control arm bearing, upper, inner</u>	54921	
Consisting of:		
. Spring washer	906994	2
. Lubricator	914169	2
. Bushing	87027	2
. Rubber seal	87028	2
. Shaft	87043	1
. Screw	107002	2
<u>Set of spare parts for control arm bearing, lower, outer</u>	54922	
Consisting of:		
. Lubricator	951739	1
. Nut	17620	1

<u>Description</u>	<u>Tools</u>	
	<u>Sets of spare parts</u>	
	<u>Part No.</u>	<u>Qty.</u>
. Lock washer	18872	2
. Bolt	87020	1
. Rubber spacer	87022	2
. Bushing	87024	1

1. From chassis No. 80523 onwards as well as Nos. 76001-76092, 76094-80521.
2. Up to chassis No. 84390 except Nos. 83278-83280, 83338-83342, 84259-84296.
3. From chassis No. 84391 onwards as well as Nos. 83278-83280, 83338-83342, 84259-84296.