

INDEX

See also Alphabetical Register on page 188

<u>Section</u>	<u>Page No.</u>
<u>ENGINE BLOCK</u>	
. Cylinder block, side covers for push rods, breather pipe, timing gear casing	5
. Flywheel housing	6
. Cylinder head, induction manifold	7
. Exhaust manifold, valve cover	8
. <u>Crankshaft and appurtenant parts</u>	
. . Pistons, piston rings, gudgeon pin	9
. . Connecting rods, crankshaft, crankshaft gear, flywheel	10
. . Crankshaft bearings	10
. <u>Valve mechanism</u>	
. . Valves, rocker arms	12
. . Push rods, camshaft, camshaft gear	13
. <u>Engine mountings</u>	13
<u>LUBRICATION AND COOLING</u>	
. <u>Lubricating system</u>	
. . Oil pump, oil sump	14
. . Oil relief valve, dipstick	15
. . Oil filter	15
. <u>Cooling system</u>	
. . Water pump, fan, fan belt	18
. . Thermostat housing	18
. . Thermostat, radiator hoses, radiator unit, radiator blind	19
<u>ELECTRICAL EQUIPMENT</u>	
. Distributor	20
. Ignition coil	27
. Sparking plugs, ignition cables	27
. Dynamo	28
. Dynamo relay, dynamo mountings	34

<u>Section</u>	<u>Page No.</u>
. Starter motor	36
. Battery	40
. Horn	40
. Headlights	41
. Stop and tail lights	43
. Instrument lighting	44
. Foot-dipper switch, lighting and other switches	45
. Interior lighting, directional indicators	46
. Electrical cables	49
. Connectors, fuseboxes, fuses	53

FUEL AND EXHAUST SYSTEMS

. <u>Fuel system</u>	
. . Fuel tank, fuel gauge tank unit, fuel lines	54
. . Fuel pump	55
. . Carburetter	57
. . Air filter	62
. <u>Exhaust system</u>	
. . Exhaust pipe	64
. . Silencer	65

POWER TRANSMISSION

. Clutch, clutch plate, release bearings	66
. Clutch controls	67
. Gearbox	68
. Speedometer gear	70
. Gearbox mountings	72
. Propeller shafts, centre bearing	73

FRONT AND REAR AXLES

. <u>Front axle section</u>	
. . Front suspension cross member, steering knuckles, king pins, steering knuckle supports	76
. . Tie rod	77
. . Steering rods	78
. . Independent suspension, front springs	79

<u>Section</u>	<u>Page No.</u>
. . Shock absorbers	80
. . Stabilizer bar	81
. <u>Rear axle</u>	
. . Rear axle housing, rear axle gear	84
. . Axle shafts (final drive)	85
. . Rear axle mountings	93
. . Rear springs, shock absorbers	94
. <u>Hubs and wheels</u>	96
<u>BRAKES</u>	
. Front wheel brake components	99
. Rear wheel brake components	102
. Foot brake control	105
. Master cylinder	106
. Brake lines	107
. Handbrake	108
<u>OPERATING CONTROLS</u>	
. Steering gear	110
. Steering wheel	113
. Pitman arms	114
. Throttle controls	116
. Pull devices	117
. Instruments	118
. Speedometer cables	120
<u>CHASSIS AND BODY UNITS</u>	
. Mudguards	122
. Wheel housing plating, protector plate for engine	123
. Front section, bonnet	124
. Bonnet hinges	125
. Bumpers	127
<u>BODY</u>	
. Body assembly, cowl, side members, dashboard	130
. Instrument panel	131
. Roof, body sides	133
. Floor	134
. Mats	136

<u>Section</u>	<u>Page No.</u>
. Rear compartment	137
. Seats	138
. Seat frames	139
. Doors	141
. Window regulators, door stops	142
. Lock cylinder, door handles	143
. Windows	143
<u>MISCELLANEOUS EQUIPMENT</u>	
. Heater unit	148
. Armrests, ashtrays	153
. Rear view mirror, cigarette lighter, windscreen wipers	154
<u>TOOLS</u>	156
<u>SETS OF SPARE PARTS</u>	156
<u>NUMERICAL REGISTER</u>	163
<u>ALPHABETICAL REGISTER</u>	188