



Fig.21

Clutch control linkage

Fig. No.	Description	Part No.	Qty.
CLUTCH CONTROL LINKAGE			
<u>Clutch pedal</u> , consisting of:			
21- 1	. Clutch pedal, upper section	657113	1
21- 2	. Clutch pedal, lower section, cpl.	87110	1
21- 3	. . Bushing	83154	2
21- 4	. Clamp screw	902280	1
21- 5	Rubber pad	83079	1
21- 6	Rubber seal	87130	1
21- 7	Washer	87487	1
21- 8	<u>Shaft</u>	87404	1
21- 9	Lubricator	180224	1
21-10	Plug	952075	1
21-11	Rubber seal	87491	2
21-12	Rubber seal	87490	1
21-13	Washer	87489	1
21-14	Lock ring	914451	2
21-15	Support plate	87115	1
21-16	Bolt, l = 9/16"	101924	1
21-17	Bolt, l = 3"	902291	1
21-18	Nut	906576	1
21-19	Spring washer	906990	2
21-20	<u>Thrust link</u>	87120	1
21-21	Cotter pin	907844	2
21-22	<u>Intermediary shaft</u>	87116	1
21-23	Felt ring	19238	1
21-24	Washer	120135	1
21-25	Cotter pin	907844	1
21-26	Anchorage	655993	1
21-27	Bolt	902279	2
21-28	Spring washer	906990	2
21-29	Lubricator	914170	1
21-30	Rubber bushing	655995	1
21-31	Sleeve	655996	1
21-32	<u>Thrust link</u>	660045	1
21-33	Adjuster nut	655983	1
21-34	Lock nut	951209	1
21-35	Cotter pin	907844	1
21-36	Rubber bushing	655985	1
21-37	Shell	655984	1
21-38	Washer	656823	1