



Fig. 11

Fig. No.	Description	Part No.
	<u>Generator, cpl., Bosch LJ/GG 200/6/2300 R 7</u>	233630
	. Housing	N.S.S.
	. Pole terminal	N.S.S.
11- 1	. Screw	190888
11- 2	. Field winding, coil 1	233755
11- 3	. Field winding, coil 2	233756
11- 4	. Insulating strip	233757
11- 5	. Screw, D plus	233758
11- 6	. Screw, "DF"	233760
11- 7	. Insulating plate	233759
11- 8	. Insulating bushing	190575
11- 9	. Insulating washer	120023
11-10	. Nut	906574
11-11	. Lock washer	190577
11-12	. Connecting screw, D minus	940102
11-13	. Lock washer	190577
11-14	. Brush retainer	238472
11-15	. Insulating plate	233763
11-16	. Insulating plate	233777
11-17	. Rivet	233765
11-18	. Insulating bushing	233767
11-19	. Insulating washer	233768
11-20	. Base washer	76820
11-21	. Base plate	233764
11-22	. Rivet	233766
11-23	. Connecting elbow	233778
11-24	. Base plate	233779
11-25	. Rivet	233780
	. Carbon brush set, cpl.	238479
11-26	. . Carbon brush	N.S.S.
11-27	. Screw	115103
11-28	. Spring washer	906983
11-29	. Brush spring	233770
11-30	. <u>End frame</u>	233771
11-31	. End frame	233772
11-32	. Spring ring	233667

Generator

Fig. No.	Description	Part No.	Qty.
11-33	. Screw	190721	2
11-34	. Spring washer	17895	2
11-35	. Rotor, cpl.	233773	1
11-36	. . Ball bearing	11010	1
11-37	. . Splash washer (round)	77680	1
11-38	. . Splash washer (triangular)	48007	1
11-39	. . Screw	115669 ¹⁾	3
11-40	. . Splash washer (round)	233774	1
11-41	. . Spacer ring	77691	1
11-42	. . Ball bearing	11009	1
11-43	. . Splash washer	233775	1
11-44	. . Spacer ring	233776	1
11-45	. <u>Pulley</u>	233577	1
11-46	. Nut	190718	1
11-47	. Spring washer	906998	1
11-48	. Woodruff key	910115	1
	Bolt for generator	921842	2
	Nut	950364	2
	Washer	951719	2
	<u>Bracket</u> for generator	403891	1
	Bolt	902282	3
	Rubber bushing	403877	8
	Washer	403878	8
	Spacer sleeve	403894	4
	Lock washer	403839	1
	Tensioner for generator	418009	1
	Bolt, tensioner - generator	105217	1
	Nut	191081	1
	Base washer, D = 18	120096	1
	Base washer, D = 20	191172	1
	Spring washer	18874	1
	<u>Drive belt</u> for generator and fan	951684	1
	Charging relay, Bosch: RS/UA/200/6	233506	1
	Screw	190364	3

1. Not included in complete generator.