



VOLVO  
KA 551

Fig. 13

Fig. No.	Description	Part No.	Qty
	<u>Battery</u>	- 1)	
	Base plate for battery	87253	1
	Screw	955153	2
	Tensioner for battery	651760 <sup>2)</sup>	1
	Tensioner for battery	656995 <sup>3)</sup>	1
	Tensioner screw	87251 <sup>2)</sup>	2
	Tensioner screw	659302 <sup>3)</sup>	2
	Nut	906576 <sup>2)</sup>	2
	Nut	151232 <sup>3)</sup>	2
	Bolt, tensioner - firewall	902252 <sup>2)</sup>	4
	Spring washer	906987 <sup>2)</sup>	4
	Spring for tensioner screw	658479 <sup>3)</sup>	2
	Base washer	120787 <sup>3)</sup>	2
	<u>Horn, high tone, Bosch: HO/FDG 6 5/9</u>	233995 <sup>4)</sup>	1
	Nut, early prod., 10 x 1.5	150133 <sup>4)</sup>	1
	Washer, 10.5 x 40 x 5	87506	1
	Nut, late prod., 8 x 1.25	191098 <sup>4)</sup>	1
	Washer, 8.4 x 36 x 5	191130 <sup>4)</sup>	1
	Washer, 10.5 x 25 x 3.4	11975 <sup>4)</sup>	1
	Washer, 14.5 x 38 x 3	18702 <sup>4)</sup>	1
	Rubber bushing	66089 <sup>2)</sup>	1
	<u>Horn, low tone, Bosch: FDG 6 1/9</u>	233996 <sup>5)</sup>	1
	Nut, early prod., 10 x 1.5	150133 <sup>5)</sup>	1
	Washer, 10.5 x 40 x 5	87506 <sup>5)</sup>	1
	Nut, late prod., 8 x 1.25	191098 <sup>5)</sup>	1
	Washer, 8.4 x 36 x 5	191130 <sup>5)</sup>	1
	Washer, 10.5 x 25 x 3.4	11975 <sup>5)</sup>	1
	Washer, 14.5 x 38 x 3	18702 <sup>5)</sup>	1
	Rubber bushing	66089 <sup>5)</sup>	1
	<u>Relay for horn, Bosch: SH/SE 16/2</u>	76951 <sup>5)</sup>	1
	Screw	955126 <sup>5)</sup>	2
	. Base washer	120098 <sup>5)</sup>	2
	<u>Horn components at steering wheel: see "Steering gear"</u>		
13- 1	<u>Headlight insert unit, cpl.</u>	233333 <sup>6)</sup>	2
13- 2	. Reflector with lens and gasket	233169	2
13- 3	. Socket	233334	2
13- 4	. Spring	233170	2
13- 5	Bulb	182035 <sup>6)</sup>	2
	Sealed beam unit, cpl.	661504 <sup>7)</sup>	2
	. Rubber gasket	661883 <sup>7)</sup>	2

1. Tudor 3DF6, Noack 312, SAAJ GH-13, etc.  
 2. Early prod. l = 271 mm.  
 3. Late prod. l = 256 mm.  
 4. P44403-09.

5. P44404-09.  
 6. P44403-04.  
 7. P44408-09.

Fig. No.	Description	Part No.	Qty.
13- 6	<u>Retainer</u>	88050	2
13- 7	Rubber gasket	88052	2
13- 8	Screw	115481	6
13- 9	Lock washer	951692	6
13-10	Frame	660092	2
13-11	Screw	115895	2
13-12	Slide cap	83590	2
13-13	Washer	83591	8
13-14	Adjuster screw	87690	4
13-15	<u>Protector cover, L, cpl.</u>	87680	1
	<u>Protector cover, R, cpl.</u>	87681	1
13-16	. Nut	83587	4
13-17	Rubber gasket	88051	2
13-18	Bolt	902225	8
13-19	Nut	906574	8
13-20	Lock washer	951693	8
13-21	Self-tapping screw	955153	4
13-22	Rubber bushing	88273	2
	<u>Light switch, cpl.</u>	651810	1
	. Lock screw for cable	14102	1
	. Lock screw for sheath	14836	1
	Screw for cable connection	115114	6
	Spring washer	906983	6
	<u>Push-pull mechanism, cpl., for light switch</u>	89999	1
	. Button	88462	1
	. Sleeve	309832	1
	. Nut	951209	1
	. Lock washer	951699	1
	. Cable	55192	*
	. Sheath	88783	*
	"Light" embellisher	651789	1
	<u>Foot-dimmer switch, R.B.M. Mfg. 4260</u>	307785	1
	Screw	14081	2
	Spring washer	906988	2
	Lock washer	951692	1
	Cover for foot-dimmer switch	87481	1
	Gasket	87482	1
	Screw	955125	2
	Nut	82660	2
	Rubber bushing	87687	1

\* State required length.