

Fig. No.	Description	Part No.	Qty.
13- 6	<u>Retainer</u>	88050	2
13- 7	Rubber gasket	88052	2
13- 8	Screw	115481	6
13- 9	Lock washer	951692	6
13-10	Frame	660092	2
13-11	Screw	115895	2
13-12	Slide cap	83590	2
13-13	Washer	83591	8
13-14	Adjuster screw	87690	4
13-15	<u>Protector cover, L, cpl.</u>	87680	1
	<u>Protector cover, R, cpl.</u>	87681	1
13-16	. Nut	83587	4
13-17	Rubber gasket	88051	2
13-18	Bolt	902225	8
13-19	Nut	906574	8
13-20	Lock washer	951693	8
13-21	Self-tapping screw	955153	4
13-22	Rubber bushing	88273	2
	<u>Light switch, cpl.</u>	651810	1
	. Lock screw for cable	14102	1
	. Lock screw for sheath	14836	1
	Screw for cable connection	115114	6
	Spring washer	906983	6
	<u>Push-pull mechanism, cpl., for light switch</u>	89999	1
	. Button	88462	1
	. Sleeve	309832	1
	. Nut	951209	1
	. Lock washer	951699	1
	. Cable	55192	*
	. Sheath	88783	*
	"Light" embellisher	651789	1
	<u>Foot-dimmer switch, R.B.M. Mfg. 4260</u>	307785	1
	Screw	14081	2
	Spring washer	906988	2
	Lock washer	951692	1
	Cover for foot-dimmer switch	87481	1
	Gasket	87482	1
	Screw	955125	2
	Nut	82660	2
	Rubber bushing	87687	1

\* State required length.