

FOREWORD

This catalogue concerns spare parts for our P 4440 saloon cars.

<u>Standard model</u>	<u>Chassis number series</u>
P 44403	B-series: 12005-20004
	C-series: 20005-28004
<u>Special model</u>	
P 44404	D-series: 28005-37004
	E-series: 37005-68955
	H,K-series: 68956-131917

On certain cars there is a Q stamped on the chassis number plate. This is of no significance whatsoever as far as the ordering of spare parts is concerned.

The cars are fitted with B4B engines which have Part No. 495301 up to engine No. 109484 and Part No. 495302 from engine No. 109485 onwards.

There is an index on pages 1 - 4 where the parts can be found in the main component groups into which the catalogue is divided. At the end of the catalogue there are an alphabetical register and a numerical register.

Always state the model designation, chassis number and engine number when ordering spare parts.

Both the model designation and the chassis number are stamped on a plate on the front of the cowl.

The engine designation and number are stamped on a plate on the right-hand side of the engine.

Certain larger units are designated "complete". The separate components tabulated under anyone of these units are integral with the unit concerned and need not be ordered separately. The other tabulations in the text are to show the relationship of the parts to one another from the point of view of fitting.

July, 1957.

AKTIEBOLAGET VOLVO

Gothenburg-Sweden

Fig. No.	Description	Part No.	Qty
	<u>HEATER UNIT</u>		
	<u>Heater unit, cpl.</u>	96590	1
44- 1	. <u>Casing, forward</u>	95223	1
44- 2	. <u>Casing, rear</u>	95229	1
44- 3	. <u>Screw, self-tapping</u>	955137	10
44- 4	. <u>Speed nut</u>	95258	10
44- 5	. <u>Core</u>	95180	1
44- 6	. <u>Rubber button</u>	81803	7
44- 7	. <u>Rubber spacer</u>	659856	1
44- 8	. <u>Rubber spacer</u>	95149	1
44- 9	. <u>Impeller, cpl.</u>	95217	1
44-10	. . <u>Lock screw</u>	915522	1
44-11	. <u>Motor</u>	95326	1
44-12	. <u>Anchorage plate</u>	95194	1
44-13	. <u>Rubber bushing</u>	94026	2
44-14	. <u>Rubber spacer</u>	95327	1
44-15	. <u>Screw, self-tapping</u>	955137	6
44-16	<u>Drain cock</u>	82745	1
44-17	<u>Rubber gasket</u>	95261	1
44-18	<u>Air intake</u>	95398	1
44-19	<u>Mesh</u>	95401	1
44-20	<u>Screw, self-tapping</u>	190665	5
44-21	<u>Coil hose</u>	95410	1
44-22	<u>Casing, cpl.</u>	96580	1
44-23	. <u>Shutter</u>	96576	1
44-24	. <u>Spindle</u>	96579	1
44-25	. <u>Speed nut</u>	82660	1
44-26	. <u>Base washer, Th. = 1.0</u>	951713	1
44-27	. <u>Base washer, Th. = 1.5</u>	11976	1
44-28	. <u>Clamp</u>	18335	1
44-29	. <u>Screw, self-tapping</u>	190665	1
44-30	. <u>Speed nut</u>	95258	1
44-31	<u>Stud</u>	17001	4
44-32	<u>Nut</u>	906575	4
44-33	<u>Coil hose</u>	191041	1
44-34	<u>Screw, self-tapping</u>	955125	1
44-35	<u>Base washer</u>	18709	1
44-36	<u>Heater control valve</u>	94104	1
44-37	<u>Screw, self-tapping</u>	191061	2

## Heater unit

Fig. No.	Description	Part No.	Qty.
44-38	Casing	96603 <sup>1)</sup>	1
	Casing	657122 <sup>2)</sup>	1
	Rubber collar	657117 <sup>2)</sup>	1
44-39	Screw, self-tapping	955143	2
44-40	Elbow bend	96605	1
44-41	Screw, self-tapping	955125	2
44-42	Coil hose	185550	1
44-43	Rubber hose	13569	*
44-44	Hose clamp	18998	6
44-45	Connecting pipe	16236	1
44-46	Connecting nipple	190664	1
	Control unit, cpl., Alt.1, gray	651865	1
	Control unit, cpl., Alt.2, black	655477	1
44-47	. Housing, Alt.1, gray	95362	1
	. Housing, Alt.2, black	655552	1
44-48	. Plate marked "Front, Air, Temp, Rear"	651866	1
44-49	. Speed nut	82660	2
44-50	. Rheostat switch	95501	2
44-51	. Lever and button, Alt.1, gray	97050	2
	. Lever and button, Alt.2, black	655478	2
44-52	. Shaft	95366	1
44-53	. Spacer spring	95369	1
44-54	. Washer	906824	4
44-55	. Interlock ball	26694	2
44-56	. Spring	95370	1
44-57	. Bracket	95368	1
44-58	. Clamp	18335	2
44-59	. Screw, self-tapping	955138	5
44-60	. Speed nut	95258	5
44-61	. Cable	55192	*
44-62	. Sheath	88783	*
44-63	. Cable	89027	1
44-64	. Cable	89028	1
44-65	. Cable	89430	1
44-66	Junction	182009	1
	Screw for cable connection	115002	2
	Lock washer	951690	2
	Clamp (sprung) for control unit	656473	1

1. Up to chassis No. 191021 except Nos. 182640-182739, 188418-189037, 189143-191020.

2. W. e. f. chassis No. 191022 and Nos. 182640-182739, 188418-189037, 189143-191020.

\* State required length.