



Fig. 30

Fig. No.	Description	Part No.	Qt
<u>BRAKES</u>			
<u>FRONT WHEEL BRAKES</u>			
	Front wheel brakes, cpl., L	89985 ¹⁾	1
	Front wheel brakes, cpl., R	89986 ¹⁾	1
30- 1	. Backing plate, L, cpl.	89701	1
	. Backing plate, R, cpl.	89702	1
30- 2	. . Bolt	89700	4
30- 3	. . . Base washer	120141	4
30- 4	. . . Spring washer	88995	4
30- 5	. . Adjuster cam	656337	2
30- 6	. . Adjuster cam	88997	2
30- 7	. Brake shoe, forward, L, cpl.	655667 ²⁾	1
	. Brake shoe, forward, R, cpl.	655668 ²⁾	1
30- 8	. . Brake lining, alt. 1, for bonding	88168	2
	. . Brake lining, alt. 2, for riveting	87929	2
	. . Rivet for lining No. 87929	952494	20
	. . <u>Self-adjusting unit</u> , consisting of:		
30- 9	. . Adjuster pin	87913	2
30-10	. . Damping spring	88611	2
30-11	. . Guide pin	87916	2
30-12	. . Quadrant and lever, L	651926	1
	. . Quadrant and lever, R	651927	1
	. . Quadrant	N.S.S.	
	. . Lever	N.S.S.	
30-13	. . Lock spring, L	88755	1
	. . Lock spring, R	88756	1
30-14	. . Spring	87921	2
30-15	. Brake shoe, rear, cpl.	657281 ²⁾	2
30-16	. . Brake lining, alt. 1, for bonding	88169	2
	. . Brake lining, alt. 2, for riveting	87930	2
	. . Rivet for lining No. 87930	952494	16
30-17	. Base washer	26885	8
30-18	. Spring washer	89705	4
30-19	. Lock washer	89652	4
30-20	. Return spring	87925	2
30-21	. Anchorage spring	87926	2
30-22	. <u>Wheel brake cylinder</u> , cpl.	87450	2
30-23	. . Housing	87452	2
30-24	. . Air-venting valve	87462	2
30-25	. . Plunger	87459	4
30-26	. . Rubber packing	81426	4
30-27	. . Spring	86660	2

1. Not stocked.

2. Only stocked with bonded linings.

Front wheel brakes

Fig. No.	Description	Part No.	Qty.
30-28	. . Rubber casing	87461	4
30-29	. Bolt	921802	4
30-30	. Spring washer	906987	4
30-31	Bolt	921641	8
30-32	Nut	921782	8
30-33	Spring washer	906992	8
<u>Brake drums and hubs for front wheels: see "Front axle"</u>			