



Grupp Group		4		PV 445, P 210		VOLVO	
Sida Page		20		Utgåva Issue		2	
		Växellåda M 4		M 4 Transmission (gearbox)		Reservdelskatalog Parts catalogue	
Pos Fig.	Antal Qty.	Benämning	Description	Def. nr Part No.	Anmärkning Notes		
	1	Växellåda, kompl. ....	Transmission, (gearbox), cpl. ....	254160			
1	1	. Hus, kompl. ....	. Housing, cpl. ....	656500			
2	1	. . Lager tapp ....	. . Bearing pin ....	656517			
3	3	. . Hattplugg ....	. . Plug ....	955084			
4	2	. . Pinne ....	. . Pin ....	950562			
5	1	. Propp ....	. Plug ....	190053			
6	1	. Propp ....	. Plug ....	951901			
7	1	. Lock ....	. Cover ....	656504			
8	1	. Packning ....	. Gasket ....	656505			
9	3	. Skruv ....	. Bolt ....	191703			
10	3	. Bricka ....	. Washer ....	61947			
11	1	. Lock ....	. Cover ....	656528			
12	1	. Packning ....	. Gasket ....	656531			
13	3	. Skruv ....	. Bolt ....	921840	l = 3/4"		
14	1	. Skruv ....	. Bolt ....	921846	l = 2"		
15	4	. Kopparpackning ....	. Copper packing ....	18651			
16	1	. Oljetätning ....	. Oil seal ....	19933			
17	1	. Luftningsnippel ....	. Air-venting nipple ....	951101			
18	1	. Ingående axel ....	. Main drive pinion ....	656567			
19	1	. Kullager ....	. Ball bearing ....	18431			
20	1	. Låsring, tj. = 2,0 ....	. Lock ring, Th. = 2.0 ....	190737	Alt.		
	1	. tj. = 2,1 ....	. Th. = 2.1 ....	190814			
	1	. tj. = 2,2 ....	. Th. = 2.2 ....	190815			
	1	. tj. = 2,3 ....	. Th. = 2.3 ....	191105			
21	1	. Oljeslångare ....	. Oil slinger ....	656508			
22	1	. Kugghjul, mellanaxel ....	. Gear, countershaft ....	656568			
23	48	. Rulle ....	. Roller ....	19567			
24	4	. Distansring ....	. Spacer ring ....	87176			
25	2	. Tryckbricka ....	. Thrust washer ....	656551			
26	1	. Mellanaxel ....	. Countershaft ....	656507			
27	1	. Lås ....	. Lock ....	70442			
28	1	. Skruv ....	. Screw ....	921822			
29	1	. Kopparpackning ....	. Copper packing ....	11992			
30	1	. Backhjul, kompl. ....	. Reverse gear, cpl. ....	656510	19 kugg 19 teeth		
31	1	. . Bussning ....	. . Bushing ....	S.E.S.			
32	1	. Axel ....	. Shaft ....	656512			
33	1	. Huvudaxel ....	. Main shaft ....	656513			
34	1	. Nållager, främre ....	. Needle bearing, forward ....	181273			
35	1	. Kullager ....	. Ball bearing ....	11013			
36	1	. Låsring, tj. = 2,0 ....	. Lock ring, Th. = 2.0 ....	914533	Alt.		
	1	. tj. = 2,1 ....	. Th. = 2.1 ....	190738			
	1	. tj. = 2,2 ....	. Th. = 2.2 ....	190739			
37	1	. Distansring ....	. Spacer ring ....	656527			
38	1	. Synkroniseringsnav, kompl., 3-an- 4-an ....	. Synchronising hub, cpl., 3rd and 4th .....	656565			
39	1	. . Synkroniseringsnav ....	. . Synchronising hub ....	656516			
40	3	. . Medbringare ....	. . Flange ....	656514			
41	2	. . Fjädderring ....	. . Spring ring ....	86713			
42	1	. . Kopplingshylsa ....	. . Coupling sleeve ....	656518			
43	2	. Synkroniseringskona ....	. Synchronising cone ....	656138			

Grupp Group		4		PV 445		VOLVO	
Sida Page		22		Utgåva Issue		1	
		Växellåda M 4		M 4 Transmission (gearbox)		Reservdelskatalog Parts catalogue	
Pos Fig.	Antal Qty.	Benämning	Description	Del. nr Part No.	Anmärkning Notes		
44	1	. Låsring, tj. = 2,00	. Lock ring, Th. = 2.00	190684	}	Alt.	
	1	. tj. = 2,10	. Th. = 2.10	190685			
	1	. tj. = 2,15	. Th. = 2.15	190686			
	1	. tj. = 2,25	. Th. = 2.25	190687			
45	1	. Kugghjul, 3-an	. Gear, 3rd	656569	21 kugg	21 teeth	
46	1	. Bussning	. Bushing	656520			
47	1	. Låskula	. Interlock ball	190740			
48	1	. Kugghjul, 2-an	. Gear, 2nd	656570	28 kugg	28 teeth	
49	1	. Kugghjul, 1-an	. Gear, 1st	656572	31 kugg	31 teeth	
50	2	. Distansring	. Spacer ring	656526			
51	1	. Kopplingshylsa, 1-2-an	. Coupling sleeve, 1st and 2nd	656523			
52	3	. Medbringare	. Flange	656515			
53	2	. Fjäddering	. Spring ring	86713			
54	2	. Synkroniseringskona	. Synchronising cone	656138			
55	1	. Hastighetsmätardrev	. Speedometer gear	655714			
56	1	. Medbringare	. Flange	87614			
57	1	. Mutter	. Nut	950428			
58	1	. Bricka	. Washer	906832			
59	1	. Skiftaxel, 3-4-an	. Shift rail, 3rd and 4th	656534			
60	1	. Medbringare	. Flange	656540			
61	1	. Skruv	. Screw	656553			
62	1	. Skiftgaffel	. Shift fork	656537			
63	1	. Skruv	. Screw	656553			
64	1	. Skiftaxel, 1-2-an	. Shift rail, 1st and 2nd	656533			
65	1	. Skiftgaffel	. Shift fork	656536			
66	2	. Medbringartapp	. Flange pin	656549			
67	1	. Spännstift	. Tensioner pin	951965			
68	1	. Skiftaxel, back	. Shift rail, reverse	656535			
69	1	. Skiftgaffel	. Shift fork	656538			
70	1	. Skruv	. Screw	656553			
71	1	. Skiftarm, kompl.	. Shift arm, cpl.	656539			
72	1	. . Pinne	. . Pin	950542			
73	1	. Medbringartapp	. Flange pin	656549			
74	3	. Låskula	. Interlock ball	67089			
75	3	. Fjäder	. Spring	87972			
76	1	. Skyddskåpa	. Protector casing	656529			
77	2	. Skruv	. Screw	950027			
78	2	. Kopparpackning	. Copper packing	18806			
79	1	. Lock, kompl.	. Cover, cpl.	656541			
80	1	. . Spärrtapp	. . Lock pin	656575			
81	1	. . Fjäder	. . Spring	656576			
82	1	. . Bussning	. . Bushing	656574			
83	1	. . Överfall	. . Cap	656547			
84	2	. . Nit	. . Rivet	952517			
85	1	. Spärrplåt	. Lock plate	656542			
86	2	. Bricka	. Washer	18696			
87	2	. Spärryttare	. Lock washer	951669			
88	1	. Fjäder	. Spring	656544			
89	1	. Packning	. Gasket	656548			
90	6	. Skruv	. Bolt	921824			
91	6	. Fjäderbricka	. Spring washer	190819			