



Grupp Group		4				P 110 P 210(B18)			VOLVO Reservdelskatalog Parts catalogue	
Sida Page		Utgåva Issue				Kardanaxel			Propeller shafts	
Pos Fig.	Antal Qty.				Benämning	Description	Del. nr Part No.	Anmärkning Notes		
	656554	662446	89460	656827						
1	1				Kardanaxel	Propeller shaft	656554-3			
		1			Kardanaxel	Propeller shaft	662446-4			
			1		Kardanaxel	Propeller shaft	89460-0	Lagerföres ej		
				1	Kardanaxel	Propeller shaft	656827-3			
2	1		1		. Flänsgaffel Flange yoke	87941-1			
		1		1	. Flänsgaffel Flange yoke	666183-9			
3	1		1		. Axelkors Joint cross	672037-9	87977-		
		1		1	. Axelkors Joint cross	666184-7			
4	4		4		. . Korkpackning Cork packing	-	15551-		
		4		4	. . Korkpackning Cork packing	666187-0			
5	4		4		. . Hållare Retainer	S E S			
6	4		4		. . Nållager Needle bearing	S E S			
		4		4	. . Nållager Needle bearing	S E S			
7	4		4		. . Låsring Lock ring	118006-6			
		4		4	. . Låsring Lock ring	666186-2			
8	1		1		. . Smörjnippel Lubricator	192554-4	180007-		
9			1		. Kardanknut Universal joint	89963-3	Lagerföres ej		
10			1		. . Flänsgaffel Flange yoke	87941-1			
				1	. . Flänsgaffel Flange yoke	666183-9			
11			1		. . Hylsgaffel Sleeve yoke	89964-1			
				1	. . Hylsgaffel Sleeve yoke	666189-6			
12			1		. . Smörjnippel Lubricator	951739-2			
				1	. . Smörjnippel Lubricator	666193-8			
13			1		. . Överfallsmutter Cap nut	87946-0			
				1	. . Överfallsmutter Cap nut	666190-4			
14			1		. . Korkpackning Cork packing	15550-7			
				1	. . Korkpackning Cork packing	666191-2			
15			2		. . Bricka Washer	18735-1			
16			1	1	. . Axelkors Joint cross		Se pos 3		
17			4	4	. . . Korkpackning Cork packing		Se pos 4		
18			4		. . . Hållare Retainer		Se pos 5		
19			4	4	. . . Nållager Needle bearing		Se pos 6		
20			4	4	. . . Låsring Lock ring		Se pos 7		
21			1		. . . Smörjnippel Lubricator		Se pos 8		
22	1				. Röraxel Tubular shaft	-	659063-		
		1			. Röraxel Tubular shaft	666188-8			
23			1		. Röraxel Tubular shaft	89965-8			
				1	. Röraxel Tubular shaft	666192-0			