



VOLVO
KA 3852

Pos Fig.	Antal Qty.	Benämning	Description	Det. nr Part No.	Anmärkning Notes
1	2	Glas	Pane	655893-6	
2	2	Tätninglist	Seal strip	96345-4	
3	1	Handtag, inre	Handle, inner	668583-8	
4	1	Pinne	Pin	92972-9	
5	1	Bricka	Washer	663599-9	
6	1	Fjäder	Spring	655762-3	
7	1	Bricka	Washer	668582-0	
8	1	Gummibricka	Rubber washer	655761-5	
9	1	Handtag, yttre	Handle, outer	668592-9	
10	1	Distanshylsa	Spacer sleeve	655760-6	
11	1	Gummibussning	Rubber bushing	659019-4	
12	1	Låscylinder	Lock cylinder	93897-7	
13	1	. Hylsa med axel Sleeve and shaft	91989-4	
14	1	. Låscylinder med 2 nycklar Lock cylinder with 2 keys	93898-5	
15	erf	Nyckel, ämne	Key, blank	660135-5	
16	1	Tätning	Seal	655532-0	
17	1	Skruv	Screw	956076-4	†4022-
18	1	Lås	Lock	96861-0	
19	1	. Fjäder Spring	656803-4	
19a	2	Gummipackning	Rubber gasket		661980
20	4	Mutter	Nut	940145-6	951098
21	4	Låsbricka	Lock washer	955948-5	951695
22	1	Länk, övre	Link, upper	96862-8	
23	1	Länk, undre	Link, lower	96863-6	
24	2	. Låskolv Lock plunger	656804-2	
25	2	. Fjäder Spring	656805-9	
26	1	Gummibussning	Rubber bushing	94100-5	
27	4	Skruv	Screw	955244-9	
28	4	Fjäderbricka	Spring washer	955918-8	906985
29	2	Låsbleck	Lock washer	663899-3	
30	erf	Bricka, tj. = 2,5	Washer, Th. = 2.5	651925-0	
	erf	Bricka, tj. = 4,0	Washer, Th. = 4.0	658805-7	
31	4	Skruv, l = 19	Screw, l = 19	956315-6	Tid utf †15889
	4	Skruv, l = 25	Screw, l = 25	956317-2	Sen utf †15918
32	2	Tätninglist	Seal strip	662706-4	
33	1	Tätninglist	Seal strip	92508-1	96384
34	2	Tätninglist	Seal strip	662715-2	