



Grupp Group		10		P 110 P 210(B18)			VOLVO	
Utgåva Issue		3		Startmotor	240360	Starter motor	Reservdelskatalog Parts catalogue	
Pos. No.	Antal Qty.	Benämning	Description	Def. nr Part No. Volvo	Def. nr Part No. Bosch			
	1	Startmotor	Starter motor	240360-8	0 001 311 001		0 001 311 001	
1	4	. Skruv	. Screw	240594-2	NSR 5576/19		2 910 550 281	
2	1	. Fältlindning, spole 1-4	. Field winding, coils 1-4	240595-9	1 004 113 502		1 004 113 502	
3	1	. Kabelgenomföring	. Grommet	240597-5	ALNB 5 L 2		1 002 380 000	
4	1	. Isolerremsa	. Insulating strip	240730-2	ALNT 1 L 1		1 002 382 000	
erf		. Isolerremsa	. Insulating strip	240596-7	ALNT 1 L 2		1 001 007 050	
10	1	. Drivlager	. Drive end bearing	240598-3	1 005 823 183		1 005 823 183	
11	1	. Lagerbussning	. Bearing bushing	238813-0	WMB 50 L 21		1 000 301 011	
12	1	. Kopplingsarm	. Engaging lever	241305-2	1 001 933 070		1 001 933 070	
13	1	. Skruv	. Screw	240622-1	WSR 30 L 38		1 003 410 003	
14	1	. Fjäderbricka	. Spring washer	955919-6	NMS 440/5		2 916 696 005	
15	1	. Mutter	. Nut	955781-0	NMU 2056/1		2 915 051 106	
16	1	. Packning	. Gasket	240599-1	ALNF 5 L 1		1 001 013 001	
17	1	. Platta	. Plate	240600-7	WPT 10 L 14		1 000 000 000	
20	1	. Rotor	. Rotor	240731-0	1 004 003 127		1 004 003 127	
22	1	. Packning	. Gasket	241306-0	WNS 13 J 48		1 000 206 001	
25	1	. Startmotordrev	. Drive with pinion	240619-7	1 006 209 047		1 006 209 047	
26	2	. Bussning	. Bushing	240620-5	WMB 50 L 19		1 000 301 009	
27	1	. Anslagsring	. Stop ring	238819-7	ALMR 5 E 9		2 000 202 030	
28	1	. Sprängring	. Spring ring	240616-3	WMR 61 L 22		1 004 601 010	
30	1	. Bricka	. Washer	240617-1	WMS 25 L 43		1 000 101 003	
31	1	. Isolerbricka	. Insulating washer	240618-9	WNS 16 L 83		1 000 112 002	
35	1	. Kommutatorlager	. Commutator end bearing	240601-5	1 005 853 385		1 005 853 385	
36	1	. Lagerbussning	. Bearing bushing	240602-3	WMB 50 L 7		1 000 301 001	
37	1	. Borsthållarplatta	. Brush holder plate	240603-1	1 004 336 005		1 004 336 005	
38	2	. Elborstsats	. Carbon brush set	240604-9	WSK 19 sort 8		1 007 014 114	
39	4	. Borstfjäder	. Brush spring	240605-6	WSF 40 L 5		1 004 652 002	
40	2	. Skruv	. Screw	956058-2	NSR 5262/9		2 910 021 116	
41	2	. Fjäderbricka	. Lock washer	239340-3	NMS 727/6		1 600 150 006	
42	1	. Packning	. Packing	240607-2	WNR 13 L 12		1 000 206 000	
43		. Justerbricka,	. Adjuster washer,					
erf		. tj. = 0,1	. Th. = 0.1	240609-8	WMS 552/30		1 000 101 016	
erf		. tj. = 0,2	. Th. = 0.2	240610-6	WMS 552/99		1 000 101 021	
erf		. tj. = 0,3	. Th. = 0.3	120657-2	WMS 552/31		1 000 101 017	
erf		. tj. = 0,5	. Th. = 0.5	240611-4	1 000 101 009		1 000 101 009	
erf		. tj. = 0,8	. Th. = 0.8	240612-2	WMS 25 L 49		1 100 101 005	
44	1	. Fixerbricka	. Setting washer	240608-0	ALMS 50 L 1		1 000 116 005	
45	1	. Skyddskåpa	. Protector casing	240606-4	ALMK 14 L 1		1 000 505 010	
46	2	. Skruv	. Screw	240613-0	WSR 30 L 37		1 003 410 002	
47	2	. Bricka	. Washer	240614-8	1 000 100 024		1 000 100 024	
55	1	. Manövermagnet	. Solenoid switch	240623-9	0 331 332 030		0 331 332 030	
57	1	. Skruv	. Screw	956059-0	NSR 5262/13		2 910 021 118	
58	1	. Underläggsplatta	. Plate	240499-4	NBE 28/4		1 901 321 203	
59		. Packning,	. Gasket,					
erf		. tj. = 0,5	. Th. = 0.5	240626-2	WNS 15 L 23		1 330 111 000	
erf		. tj. = 1,0	. Th. = 1.0	240627-0	WNS 15 L 24		1 330 111 001	
60	1	. Lock	. Switch cover	240624-7	SHDE 20 L 4		1 330 516 002	
61	3	. Fjäderbricka	. Spring washer	955918-8	NMS 440/6		2 916 693 007	
62	3	. Mutter	. Nut	955782-8	NMU 2057/1		2 915 051 107	
63	2	. Skruv	. Screw	956079-8	NSR 5639/27		2 910 051 162	
64	2	. Fjäderbricka	. Spring washer	955918-8	NMS 440/4		2 916 693 004	
65	2	. Skruv	. Screw	240628-8	WSR 50 L 12		1 003 426 000	