



Grupp Group		3		P 110 P 210(B18)			VOLVO	
Sida Page	46	Utgåva Issue	1	Elledningar Säkringsdosor, anslutningsdetaljer	Wiring Fuseboxes, connecting components	Reservdelskatalog Parts catalogue		
Pos Fig.	Antal Qty.		Benämning	Description	Del. nr Part No.	Anmärkning Notes		
	P110	P210						
1	1	1	Säkringsdosa .....	Fusebox .....	192228-5			
2	1	1	Lock .....	Cover .....	192229-3			
3	1	1	Skylt .....	Plate .....	667698-5			
4	3	3	Säkring .....	Fuse .....	11433-0	8 A		
5	1	1	Säkring .....	Fuse .....	11434-8	25 A		
6	2	2	Hylsisolator .....	Insulator .....	958215-6	<del>191671</del>		
7	3	3	Stiftisolator .....	Insulator .....	958214-9	<del>191672</del>		
8	2	2	Bryggfjäder .....	Bridge spring .....	191676-6			
9	1	1	Hylsisolator .....	Contact housing .....	958211-5	<del>191479</del>		
10	erf	erf	Kopplingsstycke .....	Connector .....	182008-3			
11	erf	erf	Gummibussning .....	Rubber bushing .....	43138-7	d = 8, D = 11		
		erf	Gummibussning .....	Rubber bushing .....	654507-3	d = 9, D = 30		
	erf	erf	Gummibussning .....	Rubber bushing .....	88273-8	d = 13, D = 20		
	erf	erf	Gummibussning .....	Rubber bushing .....	89047-5	d = 19,5, D = 27,5		
	erf	erf	Gummibussning .....	Rubber bushing .....	91395-4	d = 10, D = 16		
	erf	erf	Gummibussning .....	Rubber bushing .....	655727-6	d = 10, D = 21		
	ert	erf	Gummibussning .....	Rubber bushing .....	667075-6	d = 25, D = 33		
	erf	erf	Gummibussning .....	Rubber bushing .....	667512-8	d = 13, D = 20		
		erf	Gummibussning .....	Rubber bushing .....	95894-2	d = 11, D = 16		
12	1	1	Gummikåpa, startledning .....	Rubber casing, starter cable .....	673580-7	<del>95010</del>		
13	2	1	Clip .....	Clip .....	666211-8			
14	erf	erf	Ledningsklammer .....	Cable terminal .....	191269-0	d <sup>1</sup> = 4, d <sup>2</sup> = 2		
		erf	Ledningsklammer .....	Cable terminal .....	191270-8	d <sup>1</sup> = 4, d <sup>2</sup> = 2,4		
	erf	erf	Ledningsklammer .....	Cable terminal .....	190404-4	d <sup>1</sup> = 12,7, d <sup>2</sup> = 1,6		
	erf	erf	Ledningsklammer .....	Cable terminal .....	191404-3	d <sup>1</sup> = 10,3, d <sup>2</sup> = 1,6		
15		erf	Klammer .....	Clamp .....	951190-8	d = 10		
	erf	erf	Klammer .....	Clamp .....	951194-0	d = 19		
16	erf	erf	Skruv .....	Screw .....	955534-3	3/8" - 16 UNC x 19		
17	erf		Skruv .....	Screw .....	955119-3	86 x 10		
	erf	erf	Skruv .....	Screw .....	955120-1	86 x 12		
	erf	erf	Skruv .....	Screw .....	955122-7	86 x 16		
	erf	erf	Skruv .....	Screw .....	955126-8	88 x 10		
	erf	erf	Skruv .....	Screw .....	955140-9	88 x 16		
	erf	erf	Skruv .....	Screw .....	955136-7	810 x 8		
	erf	erf	Skruv .....	Screw .....	955137-5	810 x 10		
	erf	erf	Skruv .....	Screw .....	190953-0	812 x 10		
	erf	erf	Skruv .....	Screw .....	105829-6	812 x 16 <del>192419</del>		
18	erf	erf	Skruv .....	Screw .....	950011-7	Nr 8-32 UNC x 12,7		
	erf	erf	Skruv .....	Bolt .....	940113-4	5/16" - 18 UNC x 12,7		
	erf	erf	Skruv .....	Bolt .....	191510-7	3/8" - 16 UNC x 19		
19	erf	erf	Mutter .....	Nut .....	955782-8	M8 x 1,25-6		
20	erf	erf	Bricka .....	Washer .....	120096-3	8,4 x 18 x 1,5		
	erf	erf	Bricka .....	Washer .....	960148-5	10,5 x 20 x 2 <del>120097</del>		
21	erf	erf	Låsbricka .....	Lock washer .....	955946-9	d = 5,1 <del>951693</del>		
22	erf	erf	Fjäderbricka (elförzinkad) .....	Spring washer (zinc-plated) .....	955921-2	d = 8,2 <del>906990</del>		
	erf	erf	Fjäderbricka .....	Spring washer .....	940108-4	d = 9,7		
23	erf	erf	Jordningsskena, framstycke .....	Earth rail, front section .....	86433-0			
24	erf		Jordningsskena, nummerplåtsbelysning	Earth rail, number plate lighting	655966-0			
25	erf	erf	Kåpa, baklyktledningsuttag .....	Casing for tail lamp cable connection	658275-3	<del>667562</del>		